GR 3770

PARTS LIST

VERSION
AUGUST, 1997

PARTS LIST I

INDEX II

[ATTENTION]

- ★ If you want to orders spare parts, please make sure of what is the spare parts you want referring to Parts List, and never fail to inform us the number, name and quantity of the spare parts you want referring to Index.
- ★ It should be agreed that some parts will be modified or added without prior information.
- ★ The parts composing of an unit are marked '* ' before their names and arranged just below the name of the unit.
  In case the parts marked with '* ' is also an assembly, its components are marked ' ** ' before their names.
- ★ As the not-numbered parts in Parts List can't be ordered, please order the unit including the not-numbered parts if you want them.
- ★ The actual parts to be shipped may differ in parts number in the last three digits from those on this parts list, but they are compatible.

I. PARTS LIST

Fig. 1	MAIN BODY AREA	2
Fig. 2	ELEVATOR – SCRAPER AREA	4
Fig. 3	PAPER-FEED TRAY	6
Fig. 4	DRIVE MECHANISM AREA	8
Fig. 5	ROLLER SYSTEM AREA	12
Fig. 6	SQUEEGEE-INK PUMP UNIT AREA	14
Fig. 7	SQUEEGEE-INK PUMP UNIT AREA (Color Drum)	18
Fig. 8	DRUM-SCREEN AREA	22
Fig. 9	LOCK LEVER AREA	24
Fig. 10	CLAMP-PRESSURE CONTROL AREA	26
Fig. 11	SEPARATOR AREA	28
Fig. 12	SUCTION UNIT	30
Fig. 13	PRECISION STACKING TRAY	32
Fig. 14	ADF AREA (1)	34
Fig. 15	ADF AREA (2)	36
Fig. 16	SCANNER AREA (1)	40
Fig. 17	SCANNER AREA (2)	42
Fig. 18	MASTER-MAKING AREA (1)	44
Fig. 19	MASTER-MAKING AREA (2)	46
Fig. 20	CUTTER UNIT	48
Fig. 21	MASTER REMOVAL UNIT	50
Fig. 22	MASTER DISPOSAL BOX	52
Fig. 23	ELECTRICAL COMPONENT AREA (1)	54
Fig. 24	ELECTRICAL COMPONENT AREA (2)	56
Fig. 25	EXTERIOR COVER AREA	58
Fig. 26	STAGE COVER	60
Fig. 27	DIGITIZER	62
Fig. 28	CONNECTING PARTS FOR OPTION	64

Fig. 1 MAIN BODY AREA



No.	Part No.	Part Name	Q'ty	Remark
	017-93110-100	Magnet Catch Ass'y D; P. -Rcv.-T.; CE		
1	017-23405-307	*Bracket D; Magnet Catch; P. -Rcv.-T.; CE	1	
2	660-05000-018	*Magnet Catch SM50P	1	
	011-93110-009	Magnet Catch Ass'y; P.-Rcv.-T.		
3	011-13122-109	*Bracket; Magnet Catch; P. -Rcv.-T.	1	
4	660-05000-018	*Magnet Catch SM50P	1	
5	019-23205-108	Bracket R; Suction; A3	1	
6	019-23204-004	Bracket F; Suction; A3	1	
7	019-23403-201	Set Plate R; P. -Rcv.-T.; A3	1	
8	019-23401-209	Set Plate F; P. -Rcv.-T.; A3	1	
9	019-13119-009	Lock Plate; P. -Rcv.-T.	2	
10	011-17206-005	Bracket E; Keyboard	1	
11	011-17231-000	Set Plate Upper; Front Right Cover	1	
	019-97220-001	Keyboard Bracket D Ass'y		
12	019-17206-003	*Bracket D; Keyboard	1	
13	002-17017-203	*Cover Catch B; Front	1	
14	019-17205-007	Bracket C; Keyboard	1	
15	019-17202-008	Upper Hinge	1	
16	011-17209-004	Set Plate; Front Right Cover	1	
17	017-17210-103	Bottom Plate (Right)	1	
18	017-17220-109	Carrying Grasp	4	
19	011-34502-009	Inner Cover; CE	1	
20	019-37212-000	Bracket; Hinge; CE	1	
21	660-01000-200	Rubber Foot K-45	4	
22	019-26201-006	Fulcrum Shaft; FB	1	
23	607-09001-003	Metal; S14 x 18 x 4.5	2	
24	018-16202-007	Stepped Screw; M6 x 10	2	
25	019-46205-008	Fulcrum Support Plate; FB; CE	1	
26	014-11114-100	Bottom Cover; A3; CE	1	
27	014-14119-405	Front Cover; M.-Rmv.; A3; CE	1	
28	017-17217-205	Bottom Plate (Left); CE	1	
29	488-90021-002	Ground Wire; U3-1000-R4	1	
30	017-37224-003	Mount II; Connector; CE	1	200V
30	017-17221-008	Mount; Connector	1	100V
31	017-17222-004	Blind Plate C; Connector	2	
32	017-17223-000	Blind Plate D; Connector	2	
33	019-25006-307	Bracket; Wire Harness; CE	1	
34	019-26217-000	Bracket; Back Cover; CE	1	
35	019-26218-103	Upper Rear Frame; FB; CE	1	
36	019-60014-002	Switch A; CE	1	
37	017-16121-000	Bracket; Upper Cover Set SW	1	
38	017-16122-006	Shaft A; Upper Cover Set SW	1	
39	017-16123-002	Shaft B; Upper Cover Set SW	1	
40	017-16124-106	Spring; Upper Cover Set SW	1	
41	443-02004-002	Micro-SW: AM50039C331F	1	
42	550-21301-000	Seal; Master Cut	1	
42	550-21302-006	Seal; Master Cut; Pic.	1	
43	019-16067-000	Cap 2; CE	1	
44	019-17251-203	Lock Plate; Support Shaft	1	
45	019-17252-307	Hook Plate (R): FB; CE	1	
46	018-16229-100	Hook Plate (F): FB; CE	1	
47	018-16241-100	Bracket; Damper Stopper; CE	1	
48	018-16242-009	Spring; Damper Stopper	1	
49	018-16243-102	Cap; Damper Stopper	1	
50	019-11501-208	Bracket; Ground Finger	2	
51	481-30007-000	Ground Finger	2	

Fig. 2 ELEVATOR – SCRAPER AREA



No.	Part No.	Part Name	Q'ty	Remark
	019-91811-407	Scraper Ass'y; CE		
1	019-21805-108	*Shaft; Pickup Roller	1	
2		*Pin; ϕ2 x 14	2	Ref.Pg.II-27
3	011-11522-002	*Paper Guide Roller	2	
4	000-06123-007	*Stopper; Paper Guide Roller	2	
5	611-42100-001	*Pulley; P21-3M060 (HTD)	1	
6	620-31776-002	*Belt; 177-3M-6	1	
	019-11810-103	*Pickup Roller Ass'y	2	
7	006-11332-009	**Core; Pickup Roller	2	
8	019-11806-106	**Rubber Roller; Pickup	2	
9	019-11812-106	*Lock Ring	4	
10	019-11801-104	*Holder Plate; Scraper; CE	1	
11	607-16000-802	*Metal; F10 x 18/16 x 5; 22 x 1.5	2	
12	017-11818-002	*Scraper Collar	1	
13	017-11812-004	*Shaft; Scraper	1	
14	638-90000-012	*Washer; 18 x 10.4 x 0.4	1	
15	611-42600-004	*Pulley; P26-3M060 (HTD)	1	
16	019-11803-000	*Upper Arm; Scraper	1	
17	019-11804-006	*Spring; Scraper	1	
18	635-17613-004	*Stepped Screw; M3 x 4	1	
	019-91800-103	Feed Tray Safety SW Ass'y; A3; CE		
19	019-41801-109	*Cover; Pickup Roller; CE	1	
20	017-11819-009	*Spring F; Safety SW	1	
21	019-21802-109	*Bracket; Feed Tray Safety SW; CE	1	
22	443-02000-708	*Micro-SW; AM50630A331	2	
23	019-55032-000	*Wire Harness; Feed Tray Safety SW	1	
24	017-11820-007	*Spring B; Safety SW	1	
	019-91830-002	P.-F. Pressure Adj. Lever Ass'y		
25	017-11805-008	*Bracket; P.-F. Pressure Adj. Lever	1	
26	011-11810-105	*P.-F. Pressure Adj. Lever	1	
27	011-11815-000	*Spring: P.-F. Pressure Adj. Lever	1	
28	017-11808-007	*Hook; P.-F. Pressure Adj.	1	
29	019-11811-100	*Spring B; P.-F. Pressure Adj.	1	
30	660-05000-301	*Magnet Catch; SM-41	1	
31	017-60025-000	*Micro-SW Ass'y 3	1	

No.	Part No.	Part Name	Q'ty	Remark
32	017-11640-009	Bracket; Elevator Spring	1	
33	019-21602-002	Spring; Elevator	2	
34	002-11719-303	Rack; Elevator	2	
35	017-11602-301	Link Plate; Elevator	1	
36	002-11717-009	Collar; Elevator	2	
37	607-16000-403	Metal; F10 x 15/14 x 5.5; 20 x 2.5	1	
38	019-11814-206	Bracket; Upper Limit Sensor	1	
39	017-60007-001	Upper Limit Sensor	1	
40	019-91600-007	Shaft; Elevator	1	
41	443-30003-003	Sensor; LG-203D	1	
42	017-11648-000	Bracket; Lower Limit Sensor	1	
43	017-11649-006	Gear; Elevator	1	
44	017-91620-003	Unit/Elevator Motor	1	
45	607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	1	
46	607-12001-006	Metal; F5 x 10/9 x 4; 12 x 1.5	1	
47	550-20687-001	Seal; P.-Feed Pressure	1	
47	550-20688-008	Seal; P.-Feed Pressure; Pic.	1	

Fig. 3 PAPER-FEED TRAY



No.	Part No.	Part Name	Q'ty	Remark
	019-91500-207	Unit/Paper-Feed Tray; A3; CE		
	019-91501-203	Unit/Paper-Feed Tray; A3; US; CE		U.S.A.
1	011-11510-209	*Side Guide L; P. -F. -T.	1	
2	011-11509-200	*Side Guide R; P. -F. -T.	1	
3	019-11524-100	*Slide Sheet; P. -F. -T.	4	
4	019-41502-209	*Paper Feed Tray; CE	1	
4	019-41503-205	*Paper Feed Tray; US; CE	1	U.S.A.
5	011-11516-002	*L.O. Sheet	1	
6	019-21513-107	*Slide Rack; P. -F. -T.; CE	1	
7	019-21512-100	*Slide Rack F; P. -F. -T.; CE	1	
8	011-11513-003	*Collar; Slide Rack; P. -F. -T.	2	
9	019-11522-108	*Link Plate; Side Guide; P. -F. -T.	2	
10	638-90616-005	*Washer; 6.1 x 12 x 1.6	2	
11	011-11514-000	*Gear; Slide Rack; P. -F. -T.	1	
12	014-11533-006	*Spring; Slide Rack	1	
13	011-11524-005	*Adj. Dial	1	
14	019-21501-001	*Shaft B; P. -F. -T.	1	
15	019-21514-308	*Actuater Plate; P. -F. -T.; CE	1	
16	019-41517-001	*Bracket; P. -F. -T.; CE	1	
17	607-15006-009	*Metal; F8 x 16 x5; 18 x 1.1	2	
18	550-20590-105	*Seal; P. -F. -T.	1	
18	550-21121-001	*Seal; P. -F. -T.; US	1	U.S.A.
19	443-30002-007	*Sensor K; PS-R11LB	1	
20	019-55016-307	*Wire Harness II; P. -F. -T.	1	
21	019-21518-109	*Bracket; Size VR; P. -F. -T.; CE	1	
22	017-11516-103	*Size Gear; P. -F. -T.	1	
23	443-02000-708	*Micro-SW; AM50630A331	1	
24	488-90009-002	*Ground Wire; P. -F. -T.	1	
25	443-32001-008	*Sensor S; GP2A20L	1	
26	014-11529-203	*Feed Board Cover	1	
28	017-11519-102	*Lead SW Cover; P. -F. -T.; CE	1	
29	019-11521-101	*Support Plate L; Feed Board; CE	1	
30	019-11520-105	*Support Plate R; Feed Board; CE	1	
31	014-11502-003	*Shaft A; P. -F. -T.	1	
32	011-11523-106	*Adj. Nut; P. -F. -T.	1	

No.	Part No.	Part Name	Q'ty	Remark
33	019-41519-004	*Feed Board; CE	1	
34	019-11502-000	Connector Cover	1	
35		Pin; ϕ2 x 10	1	Ref.Pg.II-27
36	550-21292-108	Seal; Paper Side Guide	1	

Fig. 4 DRIVE MECHANISM AREA



No.	Part No.	Part Name	Q'ty	Remark
	019-91211-000	Unit/Main Motor; T		
1	019-91216-002	*Main Motor Ass'y; T	1	
	011-60027-106	**Photoelectron Disc.	1	
	017-60031-000	**Encoder Sensor	1	
2	002-11220-007	*Cam; Guide Roller	1	
3	011-11240-309	*Cam; Timing Roller	1	
	019-91220-107	Unit/Drive; CE		
4	019-11213-008	*Base Plate; P. -F. Clutch	1	
5	019-65001-006	*P. -F. Clutch	1	
6	019-11220-101	*Bracket; P. -F. Clutch; CE	1	
7	600-08242-006	*Bearing; 628ZZ	6	
8	600-20061-009	*Bearing; 608ZZ	1	
9	011-11208-103	*Base Shaft Plate; Slide Plate	1	
10	019-11201-000	*Idler Pulley	4	
11	002-11227-001	*Spacer; Slide Plate	6	
12	019-11209-000	*Slide Plate (Base)	1	
13	002-11225-009	*Support Block; Slide Plate	2	
14	006-11224-109	*Slide Plate (Front)	1	
15	011-11231-008	*Shaft Block; Slide Plate	1	
16	011-11230-001	*Shaft; Slide Plate	1	
17	638-90616-005	*Washer; 6.1 x 12 x 1.6	1	
18	607-13000-003	*Metal; F6 x 10/9 x 4; 12 x 1.5	2	
19	011-11220-006	*Shaft Base Block; Slide Plate	1	
20	011-11232-004	*Gear; Slide Plate	1	
21	011-11227-000	*Reinforce Plate; Slide Plate	1	
22	620-78309-003	*Belt; 830-5GT-11	1	
23	002-11291-109	*Sector Gear	1	
24	011-11296-002	Spring; Sector Gear	1	
25	017-11201-200	Bracket A; Sensor	1	
26	443-30003-003	Sensor; LG-203D	3	
	019-91227-004	Main Shaft Ass'y; A3		
27	019-91228-000	*Main Pulley; Main Shaft	1	
28	019-21201-105	*Cam; Pressure Roller; A3	1	
29	006-11216-106	Bearing House A; Main Shaft	1	
30	017-11209-405	Face Plate; Main Shaft	1	

No.	Part No.	Part Name	Q'ty	Remark
31	017-11202-001	Bracket B; Sensor	2	
	019-91231-001	P Disc Ass'y		
32	019-11238-000	*Range Adj. Plate; P Disc	1	
33	019-11235-001	*P Disc	1	
34	019-11224-000	Face Plate; Pressure Shaft	1	
35	011-11255-004	Pressure Sensor Disc	1	
36	620-97506-006	Belt; 750-3GT-6	1	
	019-91230-102	Pressure Link Ass'y		
37	017-11215-006	*Pressure Link; Bottom	1	
38	017-11214-000	*Pressure Link; Top	1	
39	019-21202-004	*Spring C; Pressure Link	1	
40	017-11217-009	*Link Boss B	1	
41	017-11224-005	*Link Spacer	1	
42	607-15002-003	*Metal; F8 x 12 x 5; 16 x 2	2	
43	017-11216-002	*Link Boss A	1	
44	638-90804-006	*Washer; 8 x 15 x 0.4	1	
45	607-70815-005	*Washer; UH3000	1	
46	011-11245-009	*Gear; Pressure Adj. Screw	1	
47	017-11227-004	*Pressure Adj. Screw	1	
48	017-11225-001	*Spring; Pressure Link	1	
49	017-11223-009	*Linking Plate; Drive Base	1	
50	017-11234-000	*Spring; Linking Plate	1	
51	019-11226-002	*Hook Lever	1	
52	019-11231-103	*Shaft; Hook Lever	1	
53	019-11230-000	*Spring; Hook Lever	1	
54	011-11289-006	*Bracket; Hook Lever Spring	1	
55	011-11280-106	*Pressure Hook	1	
56	019-65012-008	*Pressure Solenoid	1	
57	019-11225-006	Resting Position Plate; Pressure Lever	1	
	017-91206-002	Pressure Det. Ass'y		
58	017-11231-001	*Bracket A; Pressure Control	1	
59	017-11232-202	*Bracket B; Pressure Control	1	
60	443-30005-006	*Sensor; GP1A71A	1	
61	607-11001-002	*Metal; F4 x 6 x 2.2; 8 x 1	1	
62	019-11240-102	Pressure Lever	1	

No.	Part No.	Part Name	Q'ty	Remark
63	019-11223-003	Spring; Pressure Link	1	
64	019-13610-209	Bracket; Tension Pulley	1	
65	011-11254-202	Tension Pulley	1	
66	017-11208-000	Base Shaft Plate; Pressure	1	
67	011-11234-104	Main Bracket; Face Plate	2	
68	435-00025-000	Core; SFC-6	1	
69	019-18051-100	Guide; Motor Wire Harness; CE	1	
70	019-11222-007	Cover; Paper Feed Clutch; CE	1	

No.	Part No.	Part Name	Q'ty	Remark

M E M O

Fig. 5 ROLLER SYSTEM AREA



No.	Part No.	Part Name	Q'ty	Remark
1	014-91420-002	Pressure Roller Ass'y; A3	1	
	014-91410-309	Pressure Shaft Ass'y; A3; CE		
2	014-91412-000	*Pressure Shaft; A3	1	
3	002-11405-007	*Center Shaft; Pressure	1	
4	014-11406-209	*Pressure Roller Support; A3; CE	1	
5	014-11410-001	*Support Collar; A3	2	
6	002-11402-008	*Adjuster; Press.-Roll. Support	2	
7	002-11404-108	*Roller Holder; Pressure	4	
8	014-11404-206	*Guide Cover; Pressure; A3	1	
9	014-11405-008	*De-electricity Brush; A3	1	
	014-91320-008	Guide Roller Ass'y; A3		
10	014-11301-202	*Guide Roller; A3	1	
11	006-11306-008	*Gear A; Guide Roller	1	
12	002-11412-003	*Shaft Catch; Guide Roller	1	
13	002-11210-109	*Load Spring; Guide Roller	2	
14	006-11304-005	*Guide Shaft	1	
15	006-11305-109	*One-Way Spring	1	
16	006-11303-009	*Gear; Guide Roller	1	
17	600-50059-017	Bearing; FLW688ZZ	1	
	019-91310-009	Timing Roller Ass'y; A3		
18	014-11303-205	*Timing Roller; A3	1	
19	607-13000-402	*Metal; F6 x 10/9 x 6; 12 x 1.5	2	
20	006-11307-004	*Gear B; Timing Roller	1	
21	019-21302-009	*Bracket; Timing Roller	1	
22	019-21301-002	*Shaft; Timing Roller	1	
23	607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	2	
24	000-01327-100	Adj. Plate; Guide Roller; CE	1	
25	000-01328-107	Adj. Eccentric; Guide Roller; CE	1	
	019-91720-002	Unit/Guide Plate; A3		
26	019-21716-008	*Guide Plate (Upper)	1	
27	019-11702-009	*Sheet; Guide Plate	1	
28	017-60003-006	*Paper Sensor	1	
29		**Junction Connector; 6P	1	Ref.Pg.II-27
30	019-21717-004	*Guide Plate (Lower)	1	
31	017-55039-108	*Wire Harness; Guide Plate; 49	1	

No.	Part No.	Part Name	Q'ty	Remark
	019-91712-000	*Unit/Stripper (Dial)		
32	019-11744-003	**Bracket; Stripper Unit (Dial)	1	
33	019-11739-000	**Adj. Dial; Stripper	2	
34	019-11750-100	**Worm Gear Box; Stripper (Dial)	1	
35	019-11760-106	**Cam Plate; Stripper (Dial)	1	
36	019-11741-101	**Bracket; Stripper Shaft (Dial)	1	
37	019-11748-009	**Bracket; Stripper Base (Dial)	1	
38	635-17624-006	**Stepped Screw; ϕ6x2.2; M4x2.5	1	
39	019-60020-002	**Micro SW Ass'y 4 (Stack)	1	
40	019-11756-001	**Spring; Stack Paper Feed SW	1	
41	019-11755-005	**Bracket II; Stack Paper Feed SW	1	
42	019-11740-105	**Spring Stopper; Stripper (Dial)	1	
43	019-11738-003	**Spring; Stripper (Dial)	1	
44	019-11749-102	**Actuator Plate II; Stack P.-F. SW	1	
45	635-17523-005	**Stepped Screw; ϕ5x2; M3x3	1	
46	019-11742-108	**Housing; Stripper (Dial)	1	
47	019-11737-104	**Shaft; Stripper (Dial)	1	
48	019-11734-202	**Cover (STND); Stripper Sheet	1	*
49	019-11733-109	**Base; Stripper Sheet	1	
50	019-11731-009	**Stripper Sheet (SHRT); 80	1	*
51	019-55015-009	*Wire Harness J; Guide Plate	1	
52	011-11713-002	L Plate; Guide Plate	2	
53	607-17000-105	Metal; F12 x 18 x 10; 24 x 2.5	2	
*	Optional Choice			
48	019-11735-209	Cover (SHRT); Stripper Sheet		
50	019-11732-005	Stripper Sheet (SHRT); 90		
50	019-11736-000	Stripper Sheet (SHRT); U		
50	019-11764-004	Stripper Sheet (SHRT); 70		
50	019-11765-000	Stripper Sheet (SHRT); 60		

FIG .6 SQUEEGEE-INK PUMP UNIT AREA



No.	Part No.	Part Name	Q'ty	Remark
	019-92200-002	Unit/Squeegee; A3		
1	014-12201-104	*Squeegee Stay; A3	1	
2	000-02254-506	*Ink Blocking Plate (Front)	1	
3	002-12219-002	*Adj. Boss; Ink Blocking	2	
4	019-12206-005	*Adj. Plate (Front); Squeegee	1	
5	014-12227-103	*Reverse Rotation Stopper AII	1	
6	640-60080-001	*O Ring; P8-1.9	2	
7	601-10192-005	*Bearing; 6800ZZ	2	
8	000-02211-009	*Spring; Squeegee Gap	2	
9	002-12234-001	*Spring; Adj. Plate (Front)	2	
10	002-12213-101	*Sector Adjustor; Squeegee	1	
11	002-12240-001	*Shaft Catch; Drive; Squeegee	1	
12	002-12209-007	*Adj. Collar A; Squeegee	1	
13	011-12211-302	*Side Frame; Squeegee	1	
14	640-60140-012	*O Ring; P14-2.4	2	
15	014-12221-407	*Squeegee Roller; A3	1	
16	014-12226-000	*Doctor Roller II; A3	1	
17	014-12252-000	*Drive Shaft; Squeegee; A3	1	
18	014-12251-004	*Adj. Shaft; Squeegee; A3	1	
19	019-12207-001	*Adj. Plate (Back); Squeegee	1	
20	000-02255-502	*Ink Blocking Plate (Back)	1	
21	019-22206-003	*Reverse Rotation Stopper B	1	
22	638-90000-020	*Washer; 18 x 10.2 x 0.2	3	
23	011-12205-000	*Pulley; Squeegee Roller	1	
24	019-12208-008	*Spacer; 18 x 10 x 1.8	2	
25	640-70030-100	*V Ring; VRY2.7 x 3.5 x 4.1	1	
26	002-12238-104	*Axis; Drive Shaft; Squeegee	1	
27	607-10000-010	*Metal; F3 x 5 x 3; 8 x 1.4	1	
28	002-12229-105	*Tensioner; Squeegee	1	
29	002-12233-005	*Spring; Tensioner; Squeegee	1	
30	011-12221-006	*Fulcrum; Tensioner; Squeegee	1	
31	011-12241-007	*Shaft Support II; Squeegee	1	
	011-12206-406	*Ass'y; Shaft Joint	1	
32		**Pulley; Main Shaft	1	
33		**Shaft Joint	1	

No.	Part No.	Part Name	Q'ty	Remark
34		**Bearing Holder A; Squeegee	1	
35		**Bearing; 6202ZZ	1	
36	002-12210-005	*Adj. Collar B; Squeegee	1	
37	620-21209-002	*Squeegee Belt; B120M x L-9.5	1	
38	011-12222-401	Bracket R; Drum Cover F	1	
39	011-12223-408	Bracket L; Drum Cover F	1	
40	011-12213-100	Drum Cover F (Upper)	1	
41	011-12224-005	Drum Cover F (Lower)	1	
	017-92300-002	Unit/Drum Frame		
42	000-01169-106	*Support Roller; Drum	3	
43	002-12410-004	*Adj. Plate; Support Roller	1	
44	002-12409-103	*Support Shaft; Support Roller	2	
45	017-12201-602	*Frame; Drum	1	
46	019-12315-009	*Shaft; Locking Plate II; Drum	1	
47	019-12307-006	*Spring; Locking Plate; Drum	1	
48	019-12314-002	*Locking Plate II; Drum	1	
49	017-12216-103	*Drum Lever	1	
50	002-12407-003	*Boss A; Drum Lever	2	
51	002-12418-102	*Spacer; Drum Lever	2	
52	014-12295-001	Lever; Bottle Stopper	1	
53	014-12297-004	Spring; Stopper Lever	1	
54	017-12211-004	Bracket; Stopper Lever	1	
55	017-12213-007	Inner Cover; Drum	1	
56	017-22301-001	Bracket II; Drum Control PCB2	1	
57	019-51005-106	Drum Control PCB2	1	
58	017-55028-106	Wire Harness; Drum (R)	1	
59	017-55029-005	Wire Harness; Drum (L)	1	
60	019-55010-104	Wire Harness; Drum Inner	1	
	014-12216-101	Bottle Guide II Ass'y		
61	011-12208-000	*Bottle Guide (Over)	1	
62	014-12217-000	*Bottle Guide II (Base)	1	
	019-92240-004	Unit/Ink Pump; 37		
63	002-12303-305	*Bracket; Inking Motor	1	
64	002-12304-107	*Piston Inking Pump	1	
65	640-60140-012	*O Ring; P14-2.4	1	

No.	Part No.	Part Name	Q'ty	Remark
66	640-60220-024	*O Ring; P22-2.4	1	
67	000-07119-100	*Coil Spring; Inking Pump	1	
68	011-12151-008	*Valve; Inking Pump	2	
69	014-12211-002	*Inking Pump Body; A3	1	
70	011-12147-108	*Coil Spring; Inking Pump; RC	1	
71	640-60100-118	*O Ring; P10A-2.4	1	
72	014-12213-005	*Ink Distributor; A3	1	
73	017-65016-602	*Inking Motor	1	
74	002-12307-203	*Linking Disc; Inking Pump	1	
75	002-12308-013	*Linking Plate; Inking Pump	1	
76	002-12309-001	*Collar; Inking Pump	2	
77	002-12310-107	*Collar Holder; Inking Pump	2	
78	019-32206-001	*Elbow; Ink Distributor	2	
79	019-60023-001	Bottle Set SW II	1	
80	019-32202-103	Bracket; Bottle SW	1	
81	019-32201-000	Spring; Bottle SW	1	
	019-92231-005	Bottle Set SW Ass'y		
82	019-32203-207	*Holder; Bottle SW	1	
83	019-60010-309	*Bottle Set SW	1	
84	019-12210-002	*Set Plate; Bottle SW	1	
85	011-12218-005	Boss; Bottle Set SW	1	
86	019-32302-000	Drum Cover (Upper)	1	
87	019-32303-007	Drum Cover (Lower)	1	
88	017-60020-300	Drum PCB	1	
	484-00000-800	*Pilot Lamp	1	
89	017-12215-107	PCB Cover; Drum	1	
90	550-21399-000	Seal; Ink (HD Black)	1	
90	552-21400-105	Seal; Ink (HD Black); Pic.	1	
90	550-21502-005	Seal; Ink (HD Black); CH	1	
	550-21293-007	Color Seal Set		
		*Seal; Ink (Blue)	1	
		*Seal; Ink (Red)	1	
		*Seal; Ink (Yellow)	1	
		*Seal; Ink (Brown)	1	
		*Seal; Ink (Green)	1	

No.	Part No.	Part Name	Q'ty	Remark
		*Seal; Ink (Marine Red)	1	
		*Seal; Ink (Bright Red)	1	
		*Seal; Ink (Purple)	1	
		*Seal; Ink (Federal Blue)	1	
		*Seal; Ink (Medium Blue)	1	
		*Seal; Ink (Grey)	1	
		*Seal; Ink (Light Grey)	1	
		*Seal; Ink (Teal)	1	
		*Seal; Ink (Burgundy)	1	
		*Seal; Ink (Fluorescent Pink)	1	
		*Seal; Ink (Fluorescent Orange)	1	

M E M O

Fig.7 SQUEEGEE-INK PUMP UNIT AREA (Colour Drum)



No.	Part No.	Part Name	Q'ty	Remark
	019-92200-002	Unit/Squeegee; A3		
1	014-12201-104	*Squeegee Stay; A3	1	
2	000-02254-506	*Ink Blocking Plate (Front)	1	
3	002-12219-002	*Adj. Boss; Ink Blocking	2	
4	019-12206-005	*Adj. Plate (Front); Squeegee	1	
5	014-12227-103	*Reverse Rotation Stopper AII	1	
6	640-60080-001	*O Ring; P8-1.9	2	
7	601-10192-005	*Bearing; 6800ZZ	2	
8	000-02211-009	*Spring; Squeegee Gap	2	
9	002-12234-001	*Spring; Adj. Plate (Front)	2	
10	002-12213-101	*Sector Adjustor; Squeegee	1	
11	002-12240-001	*Shaft Catch; Drive; Squeegee	1	
12	002-12209-007	*Adj. Collar A; Squeegee	1	
13	011-12211-302	*Side Frame; Squeegee	1	
14	640-60140-012	*O Ring; P14-2.4	2	
15	014-12221-407	*Squeegee Roller; A3	1	
16	014-12226-000	*Doctor Roller II; A3	1	
17	014-12252-000	*Drive Shaft; Squeegee; A3	1	
18	014-12251-004	*Adj. Shaft; Squeegee; A3	1	
19	019-12207-001	*Adj. Plate (Back); Squeegee	1	
20	000-02255-502	*Ink Blocking Plate (Back)	1	
21	019-22206-003	*Reverse Rotation Stopper B	1	
22	638-90000-020	*Washer; 18 x 10.2 x 0.2	3	
23	011-12205-000	*Pulley; Squeegee Roller	1	
24	019-12208-008	*Spacer; 18 x 10 x 1.8	2	
25	640-70030-100	*V Ring; VRY2.7 x 3.5 x 4.1	1	
26	002-12238-104	*Axis; Drive Shaft; Squeegee	1	
27	607-10000-010	*Metal; F3 x 5 x 3; 8 x 1.4	1	
28	002-12229-105	*Tensioner; Squeegee	1	
29	002-12233-005	*Spring; Tensioner; Squeegee	1	
30	011-12221-006	*Fulcrum; Tensioner; Squeegee	1	
31	011-12241-007	*Shaft Support II; Squeegee	1	
	011-12206-406	*Ass'y; Shaft Joint	1	
32		**Pulley; Main Shaft	1	
33		**Shaft Joint	1	

No.	Part No.	Part Name	Q'ty	Remark
34		**Bearing Holder A; Squeegee	1	
35		**Bearing; 6202ZZ	1	
36	002-12210-005	*Adj. Collar B; Squeegee	1	
37	620-21209-002	*Squeegee Belt; B120M x L-9.5	1	
38	011-12222-401	Bracket R; Drum Cover F	1	
39	011-12223-408	Bracket L; Drum Cover F	1	
40	011-12213-100	Drum Cover F (Upper)	1	
41	011-12224-005	Drum Cover F (Lower)	1	
	017-92300-002	Unit/Drum Frame		
42	000-01169-106	*Support Roller; Drum	3	
43	002-12410-004	*Adj. Plate; Support Roller	1	
44	002-12409-103	*Support Shaft; Support Roller	2	
45	017-12201-602	*Frame; Drum	1	
46	019-12315-009	*Shaft; Locking Plate II; Drum	1	
47	019-12307-006	*Spring; Locking Plate; Drum	1	
48	019-12314-002	*Locking Plate II; Drum	1	
49	017-12216-103	*Drum Lever	1	
50	002-12407-003	*Boss A; Drum Lever	2	
51	002-12418-102	*Spacer; Drum Lever	2	
52	014-12295-001	Lever; Bottle Stopper	1	
53	014-12297-004	Spring; Stopper Lever	1	
54	017-12211-004	Bracket; Stopper Lever	1	
55	017-12213-007	Inner Cover; Drum	1	
56	017-22301-001	Bracket II; Drum Control PCB2	1	
57	019-51005-106	Drum Control PCB2	1	
58	017-55028-106	Wire Harness; Drum (R)	1	
59	017-55029-005	Wire Harness; Drum (L)	1	
60	019-55010-104	Wire Harness; Drum Inner	1	
	014-12216-101	Bottle Guide II Ass'y		
61	011-12208-000	*Bottle Guide (Over)	1	
62	014-12217-000	*Bottle Guide II (Base)	1	
	019-92220-003	Unit/Ink Pump; A3		
63	002-12303-305	*Bracket; Inking Motor	1	
64	002-12304-107	*Piston Inking Pump	1	
65	640-60140-012	*O Ring; P14-2.4	1	

No.	Part No.	Part Name	Q'ty	Remark
66	640-60220-024	*O Ring; P22-2.4	1	
67	000-07119-100	*Coil Spring; Inking Pump	1	
68	011-12151-008	*Valve; Inking Pump	2	
69	014-12211-002	*Inking Pump Body; A3	1	
70	011-12147-108	*Coil Spring; Inking Pump; RC	1	
71	640-60100-118	*O Ring; P10A-2.4	1	
72	014-12213-005	*Ink Distributor; A3	1	
73	017-65016-602	*Inking Motor	1	
74	002-12307-203	*Linking Disc; Inking Pump	1	
75	002-12308-013	*Linking Plate; Inking Pump	1	
76	002-12309-001	*Collar; Inking Pump	2	
77	002-12310-107	*Collar Holder; Inking Pump	2	
78	017-60020-300	Drum PCB	1	
	484-00000-800	*Pilot Lamp	1	
79	017-12215-107	PCB Cover; Drum	1	
80	019-22203-209	Bracket; Bottle SW	1	
81	019-12211-009	Spring; Bottle SW	1	
	019-92230-203	Bottle Set SW Ass'y		
82	019-12209-004	*Holder; Bottle SW	1	
83	019-60010-309	*Bottle Set SW	1	
84	019-12210-002	*Set Plate; Bottle SW	1	
85	011-12218-005	Boss; Bottle Set SW	1	
86	019-12302-101	Drum Cover (Upper)	1	
87	019-12303-108	Drum Cover (Lower)	1	
88	550-20981-104	Seal; Ink (Black)	1	
88	550-20982-100	Seal; Ink (Black); Pic.	1	
	550-21293-007	Color Seal Set		
		*Seal; Ink (Blue)	1	
		*Seal; Ink (Red)	1	
		*Seal; Ink (Yellow)	1	
		*Seal; Ink (Brown)	1	
		*Seal; Ink (Green)	1	
		*Seal; Ink (Marine Red)	1	
		*Seal; Ink (Bright Red)	1	
		*Seal; Ink (Purple)	1	

No.	Part No.	Part Name	Q'ty	Remark
		*Seal; Ink (Federal Blue)	1	
		*Seal; Ink (Medium Blue)	1	
		*Seal; Ink (Grey)	1	
		*Seal; Ink (Light Grey)	1	
		*Seal; Ink (Teal)	1	
		*Seal; Ink (Burgundy)	1	
		*Seal; Ink (Fluorescent Pink)	1	
		*Seal; Ink (Fluorescent Orange)	1	

MEMO

FIG. 8 DRUM - SCREEN AREA



No.	Part No.	Part Name	Q'ty	Remark
	019-92120-009	Unit/Drum Screen; A3II		A3
	019-92115-005	Unit/Drum Screen; A4W		A4W
	019-92110-003	*Drum Body Ass'y; A3	1	A3
1	014-12101-002	**Drum Body; A3	1	A3
1	014-12130-002	**Drum Body; A4W	1	A4W
2	011-12139-008	**Drum Seal	2	
3	014-12103-005	**Drum Body Support (Left); A3	1	
4	019-22101-104	**Drum Body Support (Right); A3	1	
5	014-12114-007	*Seal Tape; A3	1	
6	014-12116-301	*Ink Blocking Sheet; A3	1	
	019-92410-007	*Clamp Plate Base Ass'y		
7	019-22108-206	**Clamp Plate Base	1	
8	011-12130-000	**Clamp Magnet B	1	
9	019-22111-002	**Clamp Magnet A; A3	1	
10	014-12121-607	**Sheet; Clamp Plate; A3	1	
11	019-32417-304	**Clamp Plate Ass'y; II	1	
12	014-12115-003	**Clamp Sub-Plate	1	
13	011-12114-005	**Shaft; Clamp Plate	1	
14	011-12124-108	*Compensator	1	
	011-92106-008	*Ass'y; Angular Magnet Plate		
15		**Plate II; Angular Magnet	1	
16		**Magnet TDK REC 18 D5 x 2	1	
17	011-12155-208	*Screw; Angular Magnet	1	
18	019-22102-305	*Screen Ass'y; A3	1	
19	019-22113-102	*Anti-Wrinkle Strip; Drum	1	
20	019-22112-106	*Light Absorber Strip; A3	1	
21	019-22107-102	*Spring; Screen	2	
22	019-22106-106	*Screen Hanger(Lower)	1	
23	017-12205-101	Position A Plate	1	
24	019-12214-008	Position C2 Plate	1	
25	019-12215-004	Position C1 Plate	1	
26	011-12116-202	Drum Cover R	1	

No.	Part No.	Part Name	Q'ty	Remark

FIG. 9 LOCK LEVER AREA



No.	Part No.	Part Name	Q'ty	Remark
	014-92351-004	Unit/Drum Lock		
1	014-12311-007	*Shaft; Lock	1	
2	014-12322-106	*Lock Hook; Drum Lock	1	
3	014-12324-109	*Bracket; Drum Lock	1	
4	019-65014-000	*Lock Solenoid	1	
5	014-12326-004	*Spring; Lock	1	
6	011-12311-005	Drum Catch (L)	1	
7	014-12301-109	Rail; Drum; A3	2	
8	019-12301-008	Rail B; Drum	1	
9	014-12310-108	Rail Bracket; Drum	1	
	019-92101-004	Drum Holder Ass'y		
10	017-12601-309	*Drum Holder	1	
11	019-12304-007	*Guide Block; Drum Holder	1	
12	017-12605-100	*Lever Base; Drum Holder	1	
13	017-12604-103	*Lever; Drum Holder	1	
14	017-12606-009	*Shaft; Drum Holder	1	
15	017-12607-005	*Spring; Drum Holder	1	
16	550-20983-000	Seal; Drum Holder	1	
16	550-20984-006	Seal; Drum Holder; Pic.	1	
	019-92320-008	Drum Set SW Ass'y		
17	019-12308-002	*Drum Catch (R) II	1	
18	443-00120-609	*Micro-SW; E21-91N	1	
19	019-55028-003	Wire Harness; CN15	1	*1
19	019-55096-009	Wire Harness; CN15; CE	1	*2
20	019-12223-007	Bracket A; Connector; Drum	1	
21	017-12203-001	Bracket B; Connector; Drum	1	
22	017-21108-208	Bracket; Wire Harness	1	
23	014-37203-004	Cover; Drum Lock; CE	1	

No.	Part No.	Part Name	Q'ty	Remark
*1.	All U.S.,Latin , Asia (Mtr.) models			
*2.	Europe (Pic.) model			

FIG. 10 CLAMP - PRESSURE CONTROL AREA



No.	Part No.	Part Name	Q'ty	Remark
	019-95041-002	Unit/Write Pulse Motor		
1	019-65017-107	*Write Pulse Motor	1	
2	019-35020-006	*Pulley; Write Pulse Motor	1	
3	011-15146-102	*Bracket; Write Pulse Motor	1	
4	019-15125-006	*Base Plate; Write Pulse Motor	1	
5	665-04950-205	*Nut; E-632	4	
6	620-21869-002	Belt; B186 M x L-9.5	1	
	017-95050-007	Unit/Loading Pulse Motor		
7	017-65015-207	*Loading Pulse Motor	1	
8	014-15155-006	*Mount; Loading Pulse Motor	1	
9	011-15037-109	*Bracket; Loading Pulse Motor	1	
10	009-35214-009	*Pulley PM (16); Exit Roller	1	
11	620-20714-005	Belt; B71M x L4.8	1	
	019-93602-104	Unit/Clutch; A3		
12	019-23605-505	*Clutch Cover; A3	1	
13	019-13601-200	*Gear A; Clutch	1	
14	019-13604-004	*Idler Gear; Clutch	1	
15	634-05020-000	*Collar; ϕ 5.1 x 2.5	1	
16	620-97506-006	*Belt; 750-3GT-6	1	
17	019-65007-101	*Suction Clutch	1	
18	019-13602-001	*Gear B; Clutch	1	
19	600-08168-108	*Bearing; SC866ZZNR/1K	2	
20	019-23601-208	*Bracket; Suction Drive; A3	1	
21	019-13603-105	*Drive Gear; Clutch	1	
22	019-23604-304	*Shaft; Clutch; A3	1	
	017-91266-005	Pressure Control Motor Ass'y	1	
23	017-65005-309	*Pressure Control Motor	1	
24	011-11244-002	*Gear; Pressure Control Motor	1	
25	017-11229-007	*Bracket; Pressure Control Motor	1	
	017-91240-103	Unit/Print Positioning Motor		
26	017-11240-108	*Print Positioning Motor	1	
27	019-11214-004	*Bracket; Print Positioning Motor	1	
	006-91440-001	Unit/Adj. Plate; Timing Lever		
28	002-11421-100	*Adj. Plate; Timing Lever	1	
29	006-11308-108	*Timing Lever	1	
30	006-11311-206	Spring; Timing Lever; R3	1	
	017-93220-002	Angular Sensor Ass'y		
31	017-12409-009	*Bracket; Angular Sensors	1	
32	017-60016-000	*Angular Sensor	1	
33		**Junction Connector; 4P	1	Ref.Pg.II-27
34	002-12537-403	Protection Sheet	1	
	019-92400-001	Unit/Clamp		
35	019-65019-002	*Clamp Motor	1	
36	019-32403-001	*Base Plate; Clamp	1	
37	019-32412-000	*Stopper Plate; Clamp	1	
38	607-03000-005	*Metal; S4 x 8 x 3	2	
39	019-32404-105	*Cam; Clamp	1	
40	019-32416-006	*Plate Spring; Clamp	1	
41	634-06120-009	*Collar; ϕ6 x 12	1	
42	019-32405-101	*Drive Gear; Clamp	1	
43	634-06060-006	*Collar; ϕ6 x 6	1	
44	607-13004-009	*Metal; F6 x 8 x 7; 10 x 1	1	
45	019-32411-004	*Compensator Plate	1	
46	019-32410-008	*Frame; Clamp	1	
47	019-32406-000	*Shaft; Clamp	1	
48	019-92237-003	*Clamp Switch	1	
49	019-32407-201	*Guide Plate; Clamp Cam	1	
50	019-32402-102	*Spring B; Clamp	2	
51	019-32401-009	*Spring A; Clamp	1	

FIG. 11 SEPARATOR AREA



No.	Part No.	Part Name	Q'ty	Remark
	019-93300-108	Separator Ass'y; A3; CE		
1	019-13301-109	*Separator II	1	
2	019-23301-107	*Shaft; Separator II; A3; CE	1	
3	011-13311-106	*Release Lever	1	
4	011-13301-208	*Lever; Separator	1	
5	000-01515-004	*Collar; Separator	1	
6	665-02901-002	*Power Band T10	2	
7	019-13514-005	*Air Hose; Separator	1	
	019-93320-109	Air Pump Ass'y		
8	019-13501-000	*Cylinder; Air Pump	1	
9	019-13517-004	*Cylinder Valve II; Air Pump	1	
10	019-13518-000	*Cylinder Valve Sheet; Air Pump	1	
11	640-67340-009	*O Ring; P34-3.6	1	
12	019-13516-105	*Piston Head II; Air Pump	1	
13	019-13512-002	*Arm Shaft; Air Pump	1	
14	019-13511-103	*Arm; Air Pump	1	
15	019-13504-000	*Cam Plate; Air Pump	1	
16	620-73758-004	*Belt; 375-5GT-8	1	
17	019-13503-003	*Cam Pulley; Air Pump	1	
18	019-13507-106	*Bracket; Air Pump	1	
19	011-13310-002	Hook Plate	2	
20	002-13352-202	Spring; Separator	1	
21	011-13307-206	Adj. Stopper; Separator	1	
22	011-13306-005	Collar A; Separator	2	
23	607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	2	
24	017-13301-007	Release Lever; Separator	1	
25	007-13121-100	Spring; Release Lever	1	
	019-93310-006	Separation Fan Ass'y		
26	019-65006-008	*Separation Fan	1	
27	014-13311-108	*Nozzle (Upper); Separation	1	
28	014-13310-004	*Nozzle (Lower); Separation	1	
29	014-13312-007	Bracket; Separation Fan	1	
	019-93201-207	Paper Receiving Sensor IV (Receive) Ass'y		
30	017-23314-000	*Bracket II; P. -Rcv. Sensor II (Receive)	1	
31	019-60013-200	*Paper Receiving Sensor IV (Receive)	1	
32		**Junction Connector; 6P	1	Ref.Pg.II-27

FIG, 12 SUCTION UNT



No.	Part No.	Part Name	Q'ty	Remark
	019-93200-200	Suction Unit W; A3; CE		
1	017-13201-800	*Face Cover W; Suction	1	
2	011-13220-003	*Transfer Belt	3	
3	017-13247-002	*Drive Shaft; Suction	1	
4	019-55036-103	*Wire Harness; Suction	1	
5	017-13229-209	*Adj. SW Plate; Suction	1	
6	443-02006-005	*Micro-SW; ABV1236413	2	
7	600-08168-000	*Bearing NMB; LNR-1680HH	2	
8	011-13204-008	*Pulley; Suction Motor	1	
9	607-13000-003	*Metal; F6 x 10/9 x 4; 12 x 1.5	2	
10	600-50046-004	*Bearing; FLAWBC6-12ZZA	2	
11	607-11003-005	*Metal; F4 x 6/5.6 x 5.9; 9 x 1	2	
12	620-22394-008	*Belt; 239-M x L-4.8	1	
13	019-13203-000	*Gear Pulley 38; Suction	1	
14	017-13237-104	*Fulcrum Plate II; Gear Pulley; Suction	1	
15	019-60012-204	*Paper Receiving Sensor (Send) IV	1	
16		**Junction Connector; 4P	1	Ref.Pg.II-27
17	017-13220-104	*Cover; Paper Rcv. Sensor 1	1	
18	017-13221-208	*Cover; Paper Rcv. Sensor 2	1	
19	017-13240-008	*Stay; Suction	1	
20	017-13235-004	*Idler Shaft; Suction	1	
21	017-13236-205	*Belt Idler; Suction	1	
22	019-13137-007	*Jump Wing (F); Suction; A3	1	
23	017-13205-202	*Shaft; Jump Wing	2	
24	017-13208-007	*Wing Plate; Suction	2	
25	017-13239-000	*Spring; Jump Wing (F)	1	
26	017-13211-008	*Shaft Plate; Belt Roller; Suction	1	
27	017-13216-000	*Belt Roller; Suction	1	
28	017-13210-001	*Spring; Belt Roller; Suction	1	
29	019-13138-003	*Jump Wing (R); Suction; A3	1	
30	017-13241-004	*Spring; Jump Wing (R)	1	
31	017-13219-300	*Suction Cover W (Upper)	1	
32	017-13255-005	*Side Flap (R); Suction	1	
33	017-13252-006	*Side Flap (F); Suction	1	
34	017-13257-008	*Spring; Side Flap; Suction	2	
35	017-13228-105	*SW Cam; Suction	1	
36	017-13226-102	*Wing Cam (R); Suction	1	
37	017-13222-107	*Shaft; Wing Cam; Suction	1	
38		*Pin; ϕ 2x 8	3	Ref.Pg.II-27
39	017-13225-106	*Roller Cam; Suction	1	
40	017-13224-207	*Wing Cam (F); Suction	1	
41	017-13223-006	*Cam Gear; Suction	1	
42	017-13232-102	*Bracket; Suction Fan	1	
43	019-65010-102	*Suction Fan Ass'y; CE	1	
44	017-65006-003	*Wing Motor; Suction	1	
45	017-13248-009	*Pulley; Wing Motor	1	
46	620-62256-007	*Belt; B60S3M225	1	
47	017-13246-006	*Wing Gear; Suction	1	
48	017-13242-000	*Shaft Plate; Wing Gear	1	
49	011-13206-205	*Suction Fan Cover	1	
50	017-13233-001	*Seal	1	
51	019-43201-206	Cover Plate II; Suction; CE	1	
52	435-00025-000	Core; SFC-6	1	
53	017-13258-004	De-electricity Brush; Suction	1	
54	665-02031-008	Clamp; CP2311	2	

FIG. 13 PRECISION STACKING TRAY



No.	Part No.	Part Name	Q'ty	Remark
	019-93114-053	Unit/Paper Receiving Tray W		
1	019-13125-106	*Receiving Tray Plate	1	
2	019-13102-009	*Paper Guide F; P. -Rcv. -T.	1	
3	019-13103-005	*Paper Guide R; P. -Rcv. -T.	1	
4	019-13126-005	*Frame; P. -Rcv. -T.	1	
5	019-13130-002	*Ground Plate; P. -Rcv. -T.	1	
6	019-13131-106	*Slide Rail A; P. -Rcv. -T.	1	
7	019-13132-102	*Slide Rail B; P. -Rcv. -T.	2	
8	019-13112-004	*Reinforce Plate; P. -Rcv. -T.	2	
9	019-13113-108	*Back Stop; P. -Rcv. -T.	1	
10	019-13115-208	*Flap; P. -Rcv. -T.	16	
11	019-13116-107	*Flap Cover; P. -Rcv. -T.	4	
12	015-35226-004	*Slide Plate; P. -Rcv. -T.	3	
13	015-35223-102	*Slide Base; P. -Rcv. -T.	3	
14	007-13124-109	*Base Block; Paper Guide; Rcv.	3	
15	019-13133-109	*Catch Plate; P. -Rcv. -T.	1	
16	015-35244-304	*Flap Adj. Plate; P. -Rcv. -T.	4	
17	015-35246-005	*Adj. Lever; P. -Rcv. -T.	4	
18	015-35225-300	*Plate Spring; P. -Rcv. -T.	3	
	550-21296-103	Seal; P. -Rcv. -T.; US		
	550-21298-106	Seal; P. -Rcv. -T.; Pic.		
	550-21299-102	Seal; P. -Rcv. -T.		

No.	Part No.	Part Name	Q'ty	Remark

FIG, 14 ADF UNT AREA (1)



No.	Part No.	Part Name	Q'ty	Remark
		Unit/ADF; FB		
		*ADF AREA (2)		
1	019-36526-000	*Original Guide Base (F); FB-ADF	1	
2	017-16542-005	*Roller (Lower); ADF	3	
3	017-16555-000	*Roller (Spring); ADF	3	
4	018-16590-104	*Roller Spring II; ADF	2	
5	019-36515-009	*Guide; Belt	1	
6	019-36516-005	*Sheet; Original Guide Base	1	
7	018-16568-001	*Original IN Sensor (Receive); FB-ADF	1	
8	018-16569-008	*Wire Harness; Original IN Sensor	1	
9	018-16502-108	*Glass Plate; Image Scanner	1	
10	018-16533-100	*Glass Holder R; Image Scanner	1	
11	018-16534-107	*Glass Holder L; Image Scanner	1	
12	019-36530-008	*Side Frame R; FB-ADF	1	
13	018-16508-203	*Side Frame L; FB-ADF	1	
14	018-16548-000	*Metal; 8M	1	
15	639-00405-008	*Washer; 4 x 6.5 x 0.5	1	
16	018-16578-201	*Free Bushing	1	
17	018-16554-000	*Metal; Exit Roller	1	
18	018-16592-000	*Original Guide Base (R); FB-ADF	1	
19	018-16593-006	*Exit Wheel; ADF; FB	2	
20	018-16598-105	*Bracket; ADF SW	1	
21	018-16600-002	*Actuator; ADF SW	1	
22	018-16570-006	*ADF SW; FB	1	
23	018-16571-002	*Wire Harness; FB-ADF SW	1	
24	019-36533-007	*Frame B; FB-Original Guide	1	
25	019-36537-002	*Stripper Shaft; FB-ADF	1	
26	019-36524-008	*Tray Push; FB-ADF	1	
27	019-36519-004	*Tray Spring; FB-ADF	1	
28	019-36518-008	*Stripper Tray; FB-ADF	1	
29	019-36520-002	*Stripper Pad; FB-ADF	1	
30	019-36534-003	*Stripper Arm; FB-ADF	1	
31	019-36535-000	*Spring; Stripper Arm	1	
32	018-16580-001	*Spacer; Stripper; FB-ADF	1	
33	019-36517-001	*Spring Plate; FB-ADF	1	
34	019-36509-009	*Shaft; Stripper Roller	1	
35	019-36536-006	*Stripper Roller; FB-ADF	1	
36	018-16305-507	Cover B; FB-ADF	1	
37	550-20760-000	Seal; Image Scanner	1	

Fig. 15 A.D.F. Area (2)



No.	Part No.	Part Name	Q'ty	Remark
		Unit/ADF; FB		
		*ADF AREA (1)		
1	019-36529-000	*Upper Frame; FB-ADF	1	
2	018-16543-009	*Tension Pulley A; FB-ADF	2	
3	018-16506-006	*Stopper Plate; FB-ADF	1	
4	018-16507-100	*Tension Plate; FB-ADF	1	
5	018-16510-003	*Tension Pulley B; FB-ADF	1	
6	018-16546-008	*Spacer; Main Gear; FB-ADF	1	
7	018-16503-104	*Main Gear; FB-ADF	1	
8	018-16548-000	*Metal; 8M	4	
9	018-16513-002	*Transfer Roller; FB-ADF	1	
10	018-16547-004	*Metal; 8P	2	
11	019-36539-005	*Pulley; Transfer Roller	1	
12		*Pin; ϕ 2 x 14	1	Ref.Pg.II-27
13	018-16572-009	*Belt B; 56	1	
14	018-16544-005	*Pulley; Read Roller	1	
15		*Pin; ϕ 2 x 10	1	Ref.Pg.II-27
16	018-16550-102	*Housing; Read Roller	2	
17	017-16562-006	*Spring; Read Roller	2	
18	018-16516-109	*Read Roller	1	
19	018-16585-003	*Belt; 118	1	
20	018-16545-001	*Exit Pulley; FB-ADF	1	
21	018-16559-002	*Spring L; FB-ADF	1	
22	018-16549-007	*Housing; Exit Roller	2	
23	018-16558-006	*Spring R; FB-ADF	1	
24	018-16552-008	*Spacer; Exit Roller	1	
25	018-16514-009	*Exit Roller (Upper); FB-ADF	1	
26	018-16577-000	*Bushing; FB-ADF	3	
27	018-16555-007	*De-electricity Brush A; FB-ADF	2	
28	017-16546-000	*De-electricity Brush B; ADF	1	
29	018-16591-003	*Guide Plate; FB-ADF	1	
30	018-16522-001	*Bracket; ADF Motor	1	
31	018-16561-104	*ADF Motor; FB	1	
32	018-16518-101	*Motor Cover; FB-ADF	1	
33	018-16582-004	*Bushing (2); ADF Motor	1	
34	018-16581-008	*Bushing (1); ADF Motor	1	
35	018-16583-000	*Bushing (3); ADF Motor	1	
36	017-51032-001	*ADF PCB	1	
37	018-16537-009	*Bracket; Original Regist. Sensor	1	
38	018-16565-002	*Original Regist. Sensor	1	
39	018-16535-103	*Bracket; Original Out Sensor	1	
40	018-16566-009	*Original Out Sensor	1	
41	018-16536-002	*Bracket; Original Det. Sensor	1	
42	018-16564-006	*Original Det. Sensor	1	
43	019-36528-003	*Hook Plate; FB-ADF	1	
44	018-16532-007	*Open Lever; FB-ADF	1	
45	018-16504-003	*Stepped Screw; M4 x 13	1	
46	019-36540-003	*Spring; Open Lever	2	
47	018-16575-008	*Collar; Pickup Roller; FB-ADF	1	
48	017-16530-007	*Pulley A; ADF	2	
49	019-36531-004	*Pickup Roller (Upper); FB-ADF	1	
50	017-16588-005	*Belt; 44	1	
51		*Pin; ϕ 2 x 10	1	Ref.Pg.II-27
52	018-16541-006	*Collar; Stripper Roller	1	
53	019-36536-006	*Stripper Roller; FB-ADF	1	
54	019-36532-000	*Shaft; Stripper Roller; FB-ADF	1	
55	018-16526-007	*Spacer; WHG	1	
56		*Pin; ϕ 2 x 12	1	Ref.Pg.II-27
57	017-16538-008	*Gear; ADF	1	
58	018-16563-000	*Read Pulse Motor; FB-ADF	1	
59	017-16595-001	*Mount; Read Pulse Motor	1	
60	019-36527-007	*Original Guide (F); FB-ADF	1	
61	019-36521-009	*Sheet Guide; FB-ADF	3	
62	018-16567-005	*Original IN Sensor (Send)	1	
63	018-16551-001	*Metal; 6	2	
64	019-36511-003	*Lever; Hook Plate	1	
65	019-36512-000	*Plate; Hook Plate	1	
66	019-36501-000	*Pickup Roller Frame; FB-ADF	1	
67	019-36503-000	*Lever Shutter R	1	
68	019-36504-007	*Lever Shutter L	1	

No.	Part No.	Part Name	Q'ty	Remark
69	019-36505-003	*Claw L; FB-ADF	1	
70	019-36506-000	*Claw R; FB-ADF	1	
71	019-36502-004	*Bracket; Pickup Solenoid	1	
72	019-36507-006	*Lever; Pickup	1	
73	019-36514-002	*Spring; Pickup Solenoid	1	
74	019-36538-009	*Pickup Solenoid; FB-ADF	1	
75	019-36510-007	*Link; Pickup Solenoid	1	
76	019-36523-001	*Collar; Transfer Roller	1	
77	019-36522-005	*Spacer; Transfer Roller	1	
78	019-55094-006	Wire Harness; ADF (FB)	1	

No.	Part No.	Part Name	Q'ty	Remark

MEMO

Fig. 16 Scanner Area (1)



No.	Part No.	Part Name	Q'ty	Remark
1	019-36002-109	Main Frame; FB-Scanner	1	
2	019-26214-000	Hook Shaft; FB; A3	1	
3	018-16220-200	Hook Base (F); FB-Hook Shaft	1	
4	018-16222-105	Hook Base (R); FB-Hook Shaft	1	
5	018-16218-000	Shaft; Hook Base	2	
6	018-16223-004	Spring; Hook Shaft	1	
7	019-36202-108	Bracket (F); Hook Shaft	1	
8	018-36227-103	Bracket (R); Hook Shaft	1	
9	019-36201-004	Open Lever; Hook Shaft	1	
10	019-36025-109	Back Frame; FB-Scanner	1	
11	019-96050-005	Flat Bed PCB	1	
12	018-16064-003	Blind Plate; FB-Back Frame	1	
13	018-16031-105	Bracket; FB-Pos. Sensor	2	
14	443-30003-003	Sensor; LG-203D	2	
15	018-55001-108	Wire Harness; FB	1	
16	019-36015-006	Hinge Bracket; FB-Scanner; CE	2	
17	019-36020-000	Bracket; Stage Cover Sensor	1	
18	443-30003-003	Sensor; LG-203D	1	
19	018-16035-003	Actuator Spring; Stage Cover Sensor	1	
20	018-16032-101	Actuator Stage Cover Sensor	1	
21	019-26202-800	Bottom Plate; FB-Scanner; CE	1	
22	018-16250-206	Damper Hook; FB-Scanner; CE	2	
23	019-36006-104	Stage Glass	1	
24	018-16223-004	Spring; Hook Shaft	1	
25	019-36008-000	Original Stopper	1	
26	018-16067-207	Shading Plate (R)	2	
27	481-30004-000	Gasket; 80	2	
28	018-16039-106	Glass Holder (R)	1	
29	018-16071-000	Protection Tape; Stage Glass	2	
30	018-65000-002	R Pulse Motor; FB	1	
31	018-16073-002	Shock-Absorbent Rubber	1	
32	019-36022-002	Bracket; R Pulse Motor	1	
33	019-55024-105	Wire Harness; Disposal Box Master Sensor	1	
34	017-24148-200	Disposal Box Guide; CE	1	
35	017-24151-007	Guide Collar; Disposal Box Guide	2	

No.	Part No.	Part Name	Q'ty	Remark
36	019-60000-001	Disposal Box Master Sensor	1	
37		*Junction Connector; 3P	2	Ref.Pg.II-27
38	017-24154-103	Sensor Cover; Disposal Box Guide; CE	1	
39	610-00002-207	Damper; FB	2	
40	019-16215-009	Damper Bottom Bracket	2	
41	019-16214-100	Shaft; Damper Bottom Bracket	2	
42	019-27240-102	Shaft; Damper	1	
43	019-17255-004	Support Shaft Lock	1	
44	019-55087-000	Wire Harness; Image-FBI	1	
45	019-55088-006	Wire Harness; Image-FBI Power	1	
45	019-55097-005	Wire Harness; Image-FBI Power; CE	1	Europe
46	019-55037-002	Wire Harness; Removal Guide	1	
47	019-16066-003	Cap I; CE	1	
48	019-17241-305	Shaft Stopper; Damper; CE	1	
49	019-36007-003	Glass Plate; Scanner	1	
50	019-36009-006	Glass Holder F; Scanner	1	
51	019-36010-004	Glass Holder R; Scanner	1	
52	019-36207-002	Bracket; Open Lever	1	
53	019-36023-009	Hook Plate; Scanner	1	
54	019-36203-007	Fulcrum Plate; FB-Hook Shaft	1	
55	019-36206-006	Link Plate; FB-Hook Shaft	1	
56	019-36026-008	Set Sheet A; Stage Glass	2	
57	019-36027-004	Set Sheet B; Stage Glass	4	
58	635-17814-000	Stepped Screw; M4 x 4.3	1	

Fig. 17 Scanner Area (2)



No.	Part No.	Part Name	Q'ty	Remark
1	019-36014-000	Adj. Plate; FB-Slide Shaft	2	
2	018-60000-101	Original Det. Sensor; FB	1	
3	015-27128-001	Balance Weight; FB	4	
4	019-36011-000	Drive Pulley Holder; FB-Scanner	1	
5	018-16017-005	Drive Pulley Shaft; FB-Scanner	1	
6	600-50046-004	Bearing; FLAWBC6-12ZZA	2	
7	611-30090-000	Pulley; P63/20-2M-6; HTD	1	
8	620-81966-007	Belt; 196-2GT	1	
9	620-89996-100	Belt; 1344-2GT	1	
10	018-16019-008	Belt Stand Plate; FB-Scanner	1	
11	018-16020-006	Belt Holder Plate; FB-Scanner	1	
12	018-16023-005	Tension Holder; FB-Scanner	1	
13	018-16027-000	Tension Spring; FB-Scanner	1	
14	018-16024-001	Tension Plate; FB-Scanner	1	
15	611-01420-000	Pulley; ϕ 14 x 8	1	
16	018-16022-009	Tension Shaft; FB-Scanner	1	
17	015-71001-108	Image Scanner 600	1	
17	019-60024-008	Image Scanner 600 CE	1	Europe
18	019-36016-100	Wire Stand; FB-Image	1	
19	015-58000-003	Image Flexible Wire	1	
20	435-00018-004	TDK Core; HF70SH40 x 1.3 x 8	1	
21	019-36017-009	Core Holder	1	
21	019-36028-000	Core Holder CE	1	Europe
	019-36029-007	Core Cover	1	Europe
22	019-36013-003	Slide Shaft; FB-Scanner	2	
23	019-36001-005	Slide Guide; FB-Scanner	1	
24	019-36018-102	Image Scanner Cover B	1	
25	019-36019-109	Image Scanner Cover S	1	
26	600-06172-108	Bearing; DDR-1760 x 2 ZZR	1	

No.	Part No.	Part Name	Q'ty	Remark

Fig. 18 Master Making Area (1)



No.	Part No.	Part Name	Q'ty	Remark
	019-95204-009	Unit/Master Roll Holder; 377		
1	019-35028-007	*Master Roll Holder	1	
2	019-25527-200	*Bracket; Micro-SW; M.-M.	1	
3	019-25533-005	*Actuator Plate; Micro-SW	1	
4	443-02008-008	*Micro-SW; AM50030C33	1	
5	019-55004-104	*Wire Harness; Master Loading Unit SW	1	
	019-95211-005	Guide Flange Ass'y		
6	019-15270-006	*Damper Case	1	
7	019-15273-005	*Spring; Master Holder	1	
8	019-15254-000	*Shaft Flange; Master Holder	1	
9	610-00007-004	*HG Damper, 2G50-E	1	
10	019-15253-004	*Damper Gear	1	
11	019-15255-007	*Stopper; Guide Flange	1	
12	019-35032-004	Guide Holder D; Master Holder	1	
	019-95070-100	Set Guide Plate Ass'y; A3		
13	019-60015-106	*Master End Sensor (Send)	1	
14		**Junction Connector; 4P	1	Ref.Pg.II-27
15	019-25519-002	*Set Guide Plate; A3	1	
16	019-25518-006	Stay L; Set Guide Plate	1	
17	019-25517-000	Stay R; Set Guide Plate	1	
18	019-25516-100	Set Guide Shaft	1	
19	019-25602-007	Base Plate F; Tension Roller	1	
20	600-06105-001	Bearing; DDLF - 1060ZZH	2	
21	019-25604-000	Torque Limiter; Tension Roller	1	
22	019-95600-001	Tension Roller Ass'y	1	
23	607-05001-009	*Metal; S6 x 10 x 6	1	
24	019-25603-003	Base Plate R; Tension Roller	1	
	019-95095-005	Stocker Ass'y; A3		
25	017-65011-007	*Loading Fan; Stocker	1	
26	019-25111-003	*Stocker	1	
27	019-25112-107	Stocker Cover	1	
28	019-95077-007	Write Roller, A3	1	
29	019-35024-109	Master Guide Plate; A3	1	
30	014-15146-007	Spring; Master Guide Plate	2	
31	014-15144-209	Spring Hanger L; Master Guide Plate; CE	1	

No.	Part No.	Part Name	Q'ty	Remark
32	014-15191-100	Guide Plate; Load; A3	1	
33	014-15102-000	Load Roller (Lower); M. -M.	1	
34	014-15145-205	Spring Hanger R; Master Guide Plate; CE	1	
35	019-24126-104	Bracket; Aero Guide Sheet; CE	1	
36	019-24127-100	Aero Guide Sheet; A3	1	
37	019-35021-002	Pulley G; 600	1	
38	014-15182-003	Fixing Plate; Pulley G	1	
39	017-15214-004	Holder Stay F	1	
40	017-15213-008	Holder Stay R	1	
41	011-15001-007	Support Shaft	2	
42	014-15214-002	Set Plate; Cover	1	
43	011-15110-000	Pulley; Loading Roller (Lower)	1	
44	601-10228-000	Bearing; 0900ZZNR	2	
45	017-24152-100	Bracket F; Master Removal Fan	1	
46	017-24153-107	Bracket R; Master Removal Fan	1	
47	019-65005-001	Master Removal Fan	2	
48	607-15000-809	Metal; F8 x 16 x 6; 18 x 2	2	
49	019-35008-006	Bracket; De-electricity Brush	1	
50	019-25101-105	De-electricity Brush	1	
51	019-25103-000	Protection Sheet; De-electricity Brush	1	
52	019-35035-003	Flange F; Master Roll	1	
53	019-35036-000	Flange R; Master Roll	1	
54	550-21141-002	Seal; Paper Guide Set	1	
54	550-21142-009	Seal; Paper Guide Set; Pic.	1	
55	550-20987-005	Seal; Setting Master	1	
55	550-20988-001	Seal; Setting Master; Pic.	1	
56	550-21073-007	Seal; P -Rcv. -T.; Caution	1	
57	019-35033-000	Cover; Master Roll Holder	1	

Fig. 19 MASTER-MAKING AREA (2)



No.	Part No.	Part Name	Q'ty	Remark
	019-95001-000	Unit/Master Making; A3		
	019-95002-007	Unit/Master Making; A3 CE		Europe
1	019-25532-009	*Spring (Right); M. -M.	1	
2	019-25531-002	*Spring (Left); M. -M.	1	
3	014-15021-107	*Fulcrum III; M. -M.; CE	2	
4	019-55089-100	Wire Harness; M. -M. - Image	1	
4	019-55098-001	Wire Harness; M. -M. - Image; CE	1	Europe
5	443-02007-001	*Micro-SW; AM50036C331	2	
6	011-15708-208	*Switch Cam	1	
7	019-25612-002	*Bracket; Micro-SW	1	
8	019-65016-100	*Thermal Pressure Motor Ass'y	1	
9	011-15117-005	*Cam; Thermal Pressure Motor	1	
10	014-15028-004	*Reinforce Shaft	1	
11	019-35002-105	*Frame A; M. -M.	1	
12	607-11000-200	*Metal; F4 x 7 x 6; 10 x 1.5	2	
13	014-15018-009	*Catch Roller (Upper); A3	1	
14	011-15004-006	*Fulcrum; TPH	2	
15	019-25007-001	*Shaft; Load Roller	1	
16	017-15009-001	*Load Roller	2	
17	014-15007-007	*Load Roller	1	
18	607-13000-607	*Metal; F6 x 9 x 7; 11 x 1	2	
19	019-35006-003	*Bracket; TPH; A3	1	
20	019-35016-009	*Pressure Assist Plate	2	
21	019-35015-100	*Bracket; Pressure Assist Plate; CE	2	
22	019-25511-001	*Spring; TPH Pressure	2	
23	011-15098-000	*Hook Spring	2	
24	011-15013-005	*Open/Close Hook	2	
25	014-15008-003	*Shaft; Open/Close Hook; A3	1	
26	665-04014-003	Snap Bushing; SB-2000-26	1	
27	019-51043-059	Sub-Power Supply PCB	1	
28	019-55092-100	Wire Harness; TPH Power	1	
29	019-35007-000	Cover A; M. -M.	1	
	019-95050-052	Copy Guide Plate (Lower) Ass'y		
30	019-60022-005	*Master End Sensor (Receive)	1	
31		**Junction Connector; 3P	1	Ref.Pg.II-27

No.	Part No.	Part Name	Q'ty	Remark
32	019-25605-006	*Copy Guide Plate (Lower)	1	
33	019-25608-005	*Base A; Nip Roller	1	
34	014-15013-007	*Sheet; Light Absorber; M. -M.	1	
35	014-15011-004	*De-electricity Bar; M. -M.; A3	2	
36	019-25609-001	*Base B; Nip Roller	1	
37	019-25610-000	*Nip Roller	1	
38	635-17614-000	*Stepped Screw, M4 x 4.5	2	
39	607-13003-002	*Metal; F6 x 8 x 3; 10 x 1	2	
40	550-20118-104	TPH Seal	1	
41	019-95037-056	TPH Ass'y; 600A3	1	
42	019-35037-006	Actuator Plate; Micro-SW; M. -M.	1	
43	019-55090-000	Wire Harness; TPH Power	1	
44	505-00350-102	Cap Spacer	1	
46	550-20671-105	Seal; M. -M.	1	
46	550-20672-101	Seal; M. -M.; Pic.	1	

Fig. 20 Cutter Unit



No.	Part No.	Part Name	Q'ty	Remark
	019-95100-009	Set Sheet Plate Ass'y; A3		
1	019-25115-009	*Set Sheet Plate; A3	1	
2	019-25116-005	*Set Sheet	2	
3	014-15116-205	*Set Sheet E	2	
	019-95300-202	Unit/Cutter; A3; CE		
4		*Cutter Body	1	
5	019-65008-205	**Cutter Motor Ass'y; CE	1	
	019-25309-008	**Gear; Cutter Motor	1	
6	017-15306-006	*Bracket; Master Positioning Sensor	1	
7	019-60019-101	*Master Positioning Sensor II	1	
8		*Junction Connector; 3P	1	Ref.Pg.II-27
9	019-25301-309	*Cutter Cover	1	
10	019-25307-102	*Cutter Guide	1	
11	019-25311-100	*Cutter Guide Sheet (A3)	2	
12	019-25312-300	*Cutter Center Guide Sheet	1	
13	019-25305-002	*Master Guide Stopper Plate	1	
14	019-25306-009	*Master Guide Stopper Cushion	1	

No.	Part No.	Part Name	Q'ty	Remark

Fig. 21 Master Removal Unit



No.	Part No.	Part Name	Q'ty	Remark
	019-94100-102	Unit/Master Removal; A3; CE		
1	017-44101-103	*Right-Side Frame; M. -Rmv.; CE	1	
2	017-44104-102	*Left-Side Frame; M. -Rmv.; CE	1	
3	019-44103-003	*Base Plate; M. -Rmv; A3; CE	1	
4	019-44102-007	*Stay B; M. -Rmv.; CE	1	
5	019-24101-004	*Stay A; M. -Rmv.	1	
6	019-24104-208	*Guide Plate; M. -Rmv.; A3; CE	1	
7	017-44112-008	*Set Plate R; M. -Rmv.; CE	1	
8	017-44111-001	*Set Plate F; M. -Rmv.; CE	1	
9	017-14114-006	*Set Collar; M. -Rmv.	2	
10	017-14115-002	*Screw; M. -Rmv.	2	
11	017-14116-009	*Fulcrum; Master Guide; M. -Rmv.	2	
12	019-24111-000	*Guide Plate; M. -Rmv.; A3	1	
13	019-24110-100	*Master Guide; M. -Rmv.; A3	1	
14	019-44108-102	*Upper Stay; M. -Rmv.; CE	1	
15	017-60001-208	*Master Removal Sensor	1	
16		**Junction Connector; 5P	1	Ref.Pg.II-27
17	019-24105-000	*Vertical Transport Roller (Down); A3	1	
18	612-03103-009	*Gear B; 1.25 x 14	1	
19		*Pin; ϕ 2.5 x 8	1	Ref.Pg.II-27
20	019-24107-002	*Shaft; M. -Rmv. Hook; A3	1	
21	007-17121-104	*Master Removal Hook	2	
22	011-14115-009	*Linking Plate; M. -Rmv. Hook	1	
23	000-10148-030	*Spring B	1	
24	017-60037-105	*Master Sensor II	1	
25		**Junction Connector; 3P	1	Ref.Pg.II-27
26	017-14111-309	*Sensor Bracket; M. -Rmv.	1	
27	019-65015-007	*Master Removal Solenoid	1	
28	017-14122-106	*Bracket; M. -Rmv. Solenoid	1	
29	017-65003-004	*M. -Rmv. Vertical Transport Motor	1	
30	002-14517-000	*Pulley; Duct	1	
31	019-55005-003	*Wire Harness; M. -Rmv.	1	
32	011-14408-006	*Bracket; Disposal Box SW	1	
33	443-00121-109	*Micro-SW; 21-52N	1	
34	017-60010-002	*Switch A	1	

No.	Part No.	Part Name	Q'ty	Remark
35		**Junction Connector; 2P	1	Ref.Pg.II-
27				
36	620-32916-002	*Belt; 291-3M-6	1	
37	011-14121-106	*Pulley B; M. -Rmv.	1	
38	607-13000-402	*Metal; F6 x 10/9 x 6; 12 x 1.5	2	
39	017-24109-108	*Actuator; M. -Rmv. Hook Sensor	1	
40	017-24110-009	*Bracket; M. -Rmv. Hook Sensor	1	
41	443-30005-006	*Sensor; GP1A71A	1	
42	017-24108-101	*Bracket; Disposal Box Master Sensor	1	
43	019-60001-008	*Disposal Box Master Sensor (Rcv.)	1	
44		**Junction Connector; 3P	1	Ref.Pg.II-
27				
45	017-44113-004	Fixing Plate F; M. -Rmv.; CE	1	
46	017-44114-000	Fixing Plate R; M. -Rmv.; CE	1	
	019-94115-207	Holder Ass'y; V. - Transport Roller; A3; CE		
47	019-44116-105	*Upper Holder A; V. - Transport Roller; A3; CE	1	
48	017-24141-001	*Lock Plate	2	
49	017-24140-005	*Knob Shaft; M. -Rmv.	2	
50	017-24139-104	*Knob; M. -Rmv.	2	
51	019-44112-002	*Upper Holder B; V. - Transport Roller; A3; CE	1	
52	607-13000-003	*Metal; F6 x 10/9 x 4; 12 x 1.5	2	
53	007-14113-100	*Spring; Vertical Transport	3	
54	017-24138-000	*Guide Boss; M. -Rmv.	2	
55	019-24119-108	*Vertical Transport Roller (UP); A3	1	
56	612-03103-009	*Gear B; 1.25 x 14	1	
57		*Pin; ϕ 2.5 x 8	1	Ref.Pg.II-
27				

Fig. 22 Master Disposal Box



No.	Part No.	Part Name	Q'ty	Remark
58	550-20059-108	Seal; P. -F. -T. Down	1	
	019-94130-109	Unit/Master Disposal Box; A3; CE		
1	019-44131-007	*Disposal Box; A3; CE	1	
2	011-14421-207	*Guide Cam; Disposal Box	2	
3	019-24137-009	*Guide Shaft; Disposal Box; A3	1	
4	019-24134-000	*Guide Plate; Disposal Box; A3	1	
5	011-14422-203	*Guide Spring; Disposal Box	1	
6	017-14167-002	*Guide Spring B; Disposal Box	1	
7	017-14161-101	*H. -Lever (R); Disposal Box	1	
8	019-24135-006	*Lever Frame; Disposal Box; A3	1	
9	017-14159-107	*H. -Lever (F); Disposal Box	1	
10	014-14465-001	*Lock Shaft; Disposal Box; A3	1	
11	011-14428-007	*Lock Spring (Right)	1	
12	011-14429-003	*Lock Spring (Left)	1	
13	019-24132-104	*Disposal Box Cover; A3	1	
14	017-14166-103	*Compression Plate; Disposal Box	1	
15	019-24138-005	*Shaft; Compression Plate; A3	1	
16	019-24133-003	*Disposal Box Cover B; A3	1	
17	014-14469-007	*Shaft; Disposal Box Cover; A3	1	
18	017-14163-007	*Disposal Shaft	1	
19	019-14231-007	*Hinge Reinforcement; Disposal Box	1	
20	550-20690-002	Seal; Master Disposal	1	
20	550-20691-009	Seal; Master Disposal; Pic.	1	
21	550-20693-001	Seal; Set Disposal Box	1	

No.	Part No.	Part Name	Q'ty	Remark

Fig. 23 Electrical Component Area (1)



No.	Part No.	Part Name	Q'ty	Remark
21	550-20694-008	Seal; Set Disposal Box; Pic.	1	
	019-97010-007	Unit/Operation Panel; 3770		
	019-97008-100	Unit/Operation Panel; 3770 US		
	019-97009-009	Unit/Operation Panel; 3770 Pic.		Europe, Ch
1	019-97150-003	*Key Board Cover; 3770		
2	019-97090-000	*LCD; Panel	1	
3	019-17090-307	*Reinforce Plate; Panel; CE	1	
4	017-17051-005	*Bracket B; Keyboard	1	
5	017-17050-106	*Bracket A; Keyboard	1	
6	019-17008-007	*Mylar Sheet; Panel SW	1	
7	019-51003-103	*Main SW PCB; Panel	1	
8	019-51002-107	*LCD CTL PCB	1	
9	019-17011-008	*Door; Panel	1	
10	019-17099-002	*Grand Plate; Panel	1	
11	019-17010-109	*Sheet A; Panel	2	
12	019-17009-100	*Sheet B; Panel	1	
13	019-97060-004	*Sub-Panel Ass'y; 3770	1	
13	019-97058-000	*Sub-Panel Ass'y; 3770 US	1	
13	019-97059-006	*Sub-Panel Ass'y, 3770 Pic.	1	
14	019-80031-	RPU	1	U.S.A.
14	019-80032-	RPE	1	Europe
14	019-80033-	RPA	1	Asia
15	017-17232-204	Side Cover; Power Supply	1	
16	019-51041-102	Power Supply PCB VIII H100	1	100V
16	019-51042-001	Power Supply PCB VIII H200	1	200V
17	019-17242-107	Bracket; Power Supply Fan	1	
18	019-65003-009	Fan; Power Supply	1	
19	019-55091-104	Wire Harness; Power	1	
19	019-55099-105	Wire Harness; Power; CE	1	Europe
20	019-55092-100	Wire Harness; TPH Power	1	
21	011-65022-200	Counter	1	
22	019-55078-000	Wire Harness; CN14; CE	1	
23	014-17207-100	Back Cover; Counter	1	

No.	Part No.	Part Name	Q'ty	Remark
	019-96105-101	Interlock Switch; FB		
24	443-00210-004	*Micro-SW; DDIL-AIAA	2	
25	019-16236-103	*Bracket; Interlock Switch FB	1	
26	018-16239-105	*Bracket B; Interlock Switch FB	1	
27	018-16254-007	*Plate Spring; Interlock Switch FB	1	
28	635-19404-003	*Stepped Screw; M4 x 4.5	1	
29	443-10800-209	Power Switch; AJ921001B3	1	
30	019-55025-004	Inlet Terminal; 100V	1	
30	019-55079-007	Inlet Terminal; 200V; CE	1	
31	019-18121-001	Cover Plate; Power Supply	1	
32	665-02025-504	Wire Saddle; WS-4W	3	
33	019-37209-203	Bracket; Counter; En; CE	1	
33	019-37210-201	Bracket; Counter; Pic.; CE	1	
		[For Power Supply PCB H100]		
	485-00002-401	Fuse 10A 125V 5.2 ULTS C	1	
	485-00001-804	Fuse 8A 125V 5.2 ULTS C	1	
	485-00003-408	Fuse 3.15A 125V ULTS C	5	
		[For Power Supply PCB H200]		
	485-00003-300	Fuse 5A 250V 5.2 SET	1	
	485-02520-000	Fuse 6.3A 250V 5.2 SET	1	

Fig. 24 Electrical Component Area (2)



No.	Part No.	Part Name	Q'ty	Remark
	485-00003-203	Fuse 3.15A 250V 5.2 SET	5	
1	488-00013-103	Power Cord; 100V	1	
1	488-00014-100	Power Cord; US	1	
1	488-00015-106	Power Cord; 200V	1	
1	480-00033-007	Power Cord; CH	1	
2	019-27301-004	Protection Plate; Motor Con.	1	
3	019-17236-204	Bracket; Motor Control PCB	1	
4	019-51040-106	Motor Control PCB2	1	
5	017-55017-007	Wire Harness; Motor Con.-System	1	
6	017-55031-204	Wire Harness; Elevator Motor	1	
7	019-51030-003	De-electricity PCB	1	*2
8	665-04037-003	Free Bushing; NJ-23	1	
9	019-55025-004	Inlet Terminal; 100V	1	
9	019-55079-007	Inlet Terminal; 200V; CE	1	
10	665-04014-003	Snap Bushing; SB-2000-26	2	
11	019-38101-007	Bracket (R); System PCB	1	
12	019-38102-003	Bracket (L); System PCB	1	
13	019-38107-005	Bracket; Image PCB	1	
14	019-38103-000	Cover (U); PCB	1	
15	019-51044-101	Image Processing PCB; IPIF	1	
16	019-51000-503	System PCB 2	1	
17	019-38104-006	Cover (L); PCB	1	
18	488-90021-002	Ground Wire; U3-1000-R4	1	
19	019-51047-003	Option PCB A III	1	
20	665-02040-007	Wire Saddle; LWS-2N-VO-MB6	2	
21	019-80021-	System ROM; GR	1	
22	019-18129-002	Bracket E; Option PCB; CE	1	
23	019-18130-000	Bracket F; Option PCB; CE	1	
24	408-02301-008	Battery; CR-2450	1	
25	019-55088-006	Wire Harness; Image-FBI Power	1	
25	019-55097-005	Wire Harness; Image-FBI Power; CE	1	Europe
26	019-55091-104	Wire Harness; Power	1	
26	019-55099-105	Wire Harness; Power; CE	1	Europe

No.	Part No.	Part Name	Q'ty	Remark
27	019-55087-000	Wire Harness; Image-FBI	1	
28	019-55089-100	Wire Harness; M. -M. -Image	1	
28	019-55098-001	Wire Harness; M. -M. -Image; CE	1	Europe
29	018-55016-008	Wire Harness; Image-Digitizer; CE	1	
30	019-55066-100	Wire Harness; CN7; CE	1	
31	019-55077-004	Wire Harness; Panel-System; CE	1	
32	019-55028-003	Wire Harness; CN15	1	*1
32	019-55096-009	Wire Harness; CN15; CE	1	*2
33	019-55078-000	Wire Harness; CN14; CE	1	
34	019-55014-509	Wire Harness; CN9	1	*1
*1	All U.S., Latin, Asia (Mtr.) models			
*2	Europe model			

Fig. 25 Exterior Cover Area



No.	Part No.	Part Name	Q'ty	Remark
34	019-55095-002	Wire Harness; CN9; CE	1	*2
	018-96600-008	Original Tray Ass'y; FB		
1	018-16309-200	*Original Tray; FB	1	
2	550-20682-107	*Seal; Original Size	1	
3	018-16310-101	*Original Side Guide	2	
4	017-17105-008	*Slide Rack; Original Holder	2	
5	005-24114-003	*Shaft Gear; Original Holder	1	
6	017-16021-005	*Rack Cover; ADF Cover	1	
7	019-36308-003	ADF Cover (Right); FB	1	
8	019-36307-007	ADF Cover (R); FB	1	
9	019-36306-000	ADF Cover (F); FB	1	
10	019-36301-106	Scanner Cover (F); FB	1	
11	019-36303-001	Scanner Cover (Left); FB	1	
12	019-36302-005	Scanner Cover (R); FB	1	
13	019-36304-008	Scanner Cover (Right); FB	1	
14	011-17105-306	Front Left Cover	1	
15	019-17215-002	Lower Hinge; Front	1	
16	002-17006-007	Shaft Catch; Front Cover	2	
	019-97200-000	Front Cover Ass'y		
17	019-17101-104	*Front Cover	1	
18	011-17102-005	*Magnet Catch Plate; Front	1	
19	002-17016-002	*Cover Catch A; Front	1	
	550-20998-007	*Seal; Manual Pocket	1	
20	019-17104-308	Front Right Cover	1	
21	019-27231-006	Mole; 3770	1	
22	019-35022-009	Inner Cover A	1	
23	011-37211-005	Switch Box; CE	1	
24	011-60007-008	Rotation SW; A Position	1	
25	011-60020-004	Front Cover Set SW	1	
26	014-17101-000	Back Cover; A3	1	
27	018-16312-007	Shaft; Original Tray	2	

No.	Part No.	Part Name	Q'ty	Remark

Fig. 26 Stage Cover Area



No.	Part No.	Part Name	Q'ty	Remark
28	019-36305-004	Scanner Cover (LR)	1	
	018-96200-115	Unit/Stage Cover		
1	018-16401-204	*Stage Cover; FB	1	
2	018-16413-008	*Cover B; Stage Cover	1	
3	018-96210-005	*Stage Cover Hinge Ass'y	2	
4	018-16420-004	*Actuator Plate; Stage Cover	1	
5	018-16417-100	*Balance Weight C; Stage Cover	1	
6	018-16416-104	*Balance Weight B; Stage Cover	1	
7	018-16418-000	*Cord Cap; Stage Cover	1	
8	018-16406-206	*PCB Cover; Stage Cover	1	
9	018-16411-102	*Original Holder Cover (Upper); Stage Cover	1	
10	018-16412-400	*Original Holder Cover (Lower); Stage Cover	1	
11	018-16415-701	*Balance Weight A; Stage Cover	1	
12	018-16425-006	*Stage Pad (W); Stage Cover	1	
13	488-90019-105	*Ground Wire; R4-440-R4	1	
14	435-00020-009	*Core; TR-23-11-14	1	

No.	Part No.	Part Name	Q'ty	Remark

Fig. 27 Digitizer Area



No.	Part No.	Part Name	Q'ty	Remark
15	635-11307-106	*Stepped Screw; 3 x 7	10	
1	018-16425-006	Stage Pad (W); Stage Cover	1	
2	018-96230-200	Ass'y/Digitizer Stage Cover; FB; CE	1	Europe
2	019-96220-008	Ass'y/Digitizer Cover; FB	1	
3	011-70508-005	LCD; DMF5005N	1	
4	018-16431-006	LCD Filter; Digitizer	1	
5	018-16435-001	LCD Cover; Digitizer; CE	1	Europe
5	018-16403-100	LCD Cover; Digitizer	1	
6	018-16427-203	Stylus Pen III	1	
7	665-09004-006	Stylus Pen Holder	1	
8	665-04951-104	Clip; Stylus Pen Holder	1	
9	481-30012-003	Gasket; LCDF	1	Europe
10	481-30013-000	Gasket; LCDR	1	Europe
11	018-16420-004	Actuator Plate; Stage Cover	1	
12	018-51004-803	Digitizer PCB III	1	
13	018-70017-002	INF ROM (OP); Digitizer	1	Kr, UK
13	018-70018-009	INF ROM (ST); Digitizer	1	Ja, US
13	018-70019-005	INF ROM (OP1); Digitizer	1	Gr, Fr
13	018-70020-003	INF ROM (OP2); Digitizer	1	It, Sp
14	481-30010-000	Gasket; PCB2	2	Europe
15	408-02300-001	Battery	1	
16	018-16406-206	PCB Cover; Stage Cover	1	
17	435-00027-003	Ferrite Core; SFC-10	1	Europe
18	018-55015-001	Wire Harness; Digitizer III ; CE	1	
19		SW Guide; Digitizer	1	
20	481-30009-002	Gasket; PCB1	1	Europe
21	481-30011-007	Gasket; PCB3	1	Europe
22	550-20764-006	Digitizer Seal; Ja, US	1	
22	550-20861-001	Digitizer Seal; Gr	1	
22	550-20862-008	Digitizer Seal; Fr	1	
22	550-20863-004	Digitizer Seal; It	1	
22	550-20864-000	Digitizer Seal; Sp	1	
22	550-20865-007	Digitizer Seal; In	1	
22	550-20866-003	Digitizer Seal; Ch	1	

No.	Part No.	Part Name	Q'ty	Remark

Fig. 28 Connecting Parts For Options



No.	Part No.	Part Name	Q'ty	Remark
22	550-20867-000	Digitizer Seal; Kr	1	
1	018-55016-008	Wire Harness; Image-Digitizer; CE	1	
2	018-55015-001	Wire Harness; Digitizer III; CE	1	
3	017-97300-108	Wire Harness; JS III; CE	1	
4	011-13916-008	Boss; JS Bracket	2	
5	017-13901-004	Positioning Bracket; JS III	1	
6	017-13902-000	Bracket; JS III	1	
6	019-13143-007	Job Separator Bracket EX	1	*1
7	017-55054-000	Inner COM Wire Harness; SF	1	
8	017-55049-006	Wire Harness; RA-RC Sorter Inner	1	
9	026-55040-008	Wire Harness; GR-TM2500	1	
10	019-55074-102	Wire Harness II; Counter III; CE	1	
11	017-55062-002	Wire Harness; EXE-I/F	1	
12	101-55000-002	SCII Cable (Video Cable); 10 m	1	
*13	101-55014-003	Parallel Cable (Data Type)	1	
14	025-55001-005	Wire Harness; TM-I/F	1	

II. INDEX

[NOTICE]

★ When you order spare parts, please never fail to order the parts listed in this Index after making sure of what is the spare parts you want.
★ For modified or added parts, please refer to the technical information issued by our technical department.
★ What the part No. means;

Ex.)


0 0 0 – 0 8 9 4 0 – 0 0 1
• For classification of parts
• Main number in part No.
• Surfix No.
(In case of modification this number is changed.)

● When you order spare parts, please never fail to inform us all of this part No. (the number of eleven figures).

Part No.	Part Name	Q'ty	Page	Unit Value
000-01169-106	Support Roller; Drum	6	15,19	
000-01327-100	Adj. Plate; Guide Roller; CE	1	13	
000-01328-107	Adj. Eccentric; Guide Roller; CE	1	13	
000-01515-004	Collar; Separator	1	29	
000-02211-009	Spring; Squeegee Gap	4	15,19	
000-02254-506	Ink Blocking Plate (Front)	2	15,19	
000-02255-502	Ink Blocking Plate (Back)	2	15,19	
000-06123-007	Stopper; Paper Guide Roller	2	5	
000-07119-100	Coil Spring; Inking Pump	2	16,20	
000-10148-030	Spring B	1	51	
002-11210-109	Load Spring; Guide Roller	2	13	
002-11220-007	Cam; Guide Roller	1	9	
002-11225-009	Support Block; Slide Plate	2	9	
002-11227-001	Spacer; Slide Plate	6	9	
002-11291-109	Sector Gear	1	9	
002-11402-008	Adjuster; Press.-Roll. Support	2	13	
002-11404-108	Roller Holder; Pressure	4	13	
002-11405-007	Center Shaft; Pressure	1	13	
002-11412-003	Shaft Catch; Guide Roller	1	13	
002-11421-100	Adj. Plate; Timing Lever	1	27	
002-11717-009	Collar; Elevator	2	5	
002-11719-303	Rack; Elevator	2	5	
002-12209-007	Adj. Collar A; Squeegee	2	15,19	
002-12210-005	Adj. Collar B; Squeegee	2	15,19	
002-12213-101	Sector Adjustor; Squeegee	2	15,19	
002-12219-002	Adj. Boss; Ink Blocking	4	15,19	
002-12229-105	Tensioner; Squeegee	2	15,19	
002-12233-005	Spring; Tensioner; Squeegee	2	15,19	
002-12234-001	Spring; Adj. Plate (Front)	4	15,19	
002-12238-104	Axis; Drive Shaft; Squeegee	2	15,19	
002-12240-001	Shaft Catch; Drive; Squeegee	2	15,19	
002-12303-305	Bracket; Inking Motor	2	15,19	
002-12304-107	Piston Inking Pump	2	15,19	
002-12307-203	Linking Disc; Inking Pump	2	16,20	
002-12308-013	Linking Plate; Inking Pump	2	16,20	
002-12309-001	Collar; Inking Pump	4	16,20	
002-12310-107	Collar Holder; Inking Pump	4	16,20	
002-12407-003	Boss A; Drum Lever	4	15,19	
002-12409-103	Support Shaft; Support Roller	4	15,19	
002-12410-004	Adj. Plate; Support Roller	2	15,19	
002-12418-102	Spacer; Drum Lever	4	15,19	
002-12537-403	Protection Sheet	1	27	
002-13352-202	Spring; Separator	1	29	
002-14517-000	Pulley; Duct	1	51	
002-17006-007	Shaft Catch; Front Cover	2	59	

Part No.	Part Name	Q'ty	Page	Unit Value
002-17016-002	Cover Catch A; Front	1	59	
002-17017-203	Cover Catch B; Front	1	3	
005-24114-003	Shaft Gear; Original Holder	1	59	
006-11216-106	Bearing House A; Main Shaft	1	9	
006-11224-109	Slide Plate (Front)	1	9	
006-11303-009	Gear; Guide Roller	1	13	
006-11304-005	Guide Shaft	1	13	
006-11305-109	One-Way Spring	1	13	
006-11306-008	Gear A; Guide Roller	1	13	
006-11307-004	Gear B; Timing Roller	1	13	
006-11308-108	Timing Lever	1	27	
006-11311-206	Spring; Timing Lever; R3	1	27	
006-11332-009	Core; Pickup Roller	2	5	
006-91440-001	Unit/Adj. Plate; Timing Lever	1	27	
007-13121-100	Spring; Release Lever	1	29	
007-13124-109	Base Block; Paper Guide; Rcv.	3	33	
007-14113-100	Spring; Vertical Transport	3	51	
007-17121-104	Master Removal Hook	2	51	
009-35214-009	Pulley PM (16); Exit Roller	1	27	
011-11208-103	Base Shaft Plate; Slide Plate	1	9	
011-11220-006	Shaft Base Block; Slide Plate	1	9	
011-11227-000	Reinforce Plate; Slide Plate	1	9	
011-11230-001	Shaft; Slide Plate	1	9	
011-11231-008	Shaft Block; Slide Plate	1	9	
011-11232-004	Gear; Slide Plate	1	9	
011-11234-104	Main Bracket; Face Plate	2	10	
011-11240-309	Cam; Timing Roller	1	9	
011-11244-002	Gear; Pressure Control Motor	1	27	
011-11245-009	Gear; Pressure Adj. Screw	1	9	
011-11254-202	Tension Pulley	1	10	
011-11255-004	Pressure Sensor Disc	1	9	
011-11280-106	Pressure Hook	1	9	
011-11289-006	Bracket; Hook Lever Spring	1	9	
011-11296-002	Spring; Sector Gear	1	9	
011-11509-200	Side Guide R; P. -F. -T.	1	7	
011-11510-209	Side Guide L; P. -F. -T.	1	7	
011-11513-003	Collar; Slide Rack; P. -F. -T.	2	7	
011-11514-000	Gear; Slide Rack; P. -F. -T.	1	7	
011-11516-002	L.O. Sheet	1	7	
011-11522-002	Paper Guide Roller	2	5	
011-11523-106	Adj. Nut; P. -F. -T.	1	7	
011-11524-005	Adj. Dial	1	7	
011-11713-002	L Plate; Guide Plate	2	13	
011-11810-105	P.-F. Pressure Adj. Lever	1	5	
011-11815-000	Spring: P.-F. Pressure Adj. Lever	1	5	

Part No.	Part Name	Q'ty	Page	Unit Value
011-12114-005	Shaft; Clamp Plate	1	23	
011-12116-202	Drum Cover R	1	23	
011-12124-108	Compensator	1	23	
011-12130-000	Clamp Magnet B	1	23	
011-12139-008	Drum Seal	2	23	
011-12147-108	Coil Spring; Inking Pump; RC	2	16,20	
011-12151-008	Valve; Inking Pump	4	16,20	
011-12155-208	Screw; Angular Magnet	1	23	
011-12205-000	Pulley; Squeegee Roller	2	15,19	
011-12206-406	Ass'y; Shaft Joint	2	15,19	
011-12208-000	Bottle Guide (Over)	2	15,19	
011-12211-302	Side Frame; Squeegee	2	15,19	
011-12213-100	Drum Cover F (Upper)	2	15,19	
011-12218-005	Boss; Bottle Set SW	2	16,20	
011-12221-006	Fulcrum; Tensioner; Squeegee	2	15,19	
011-12222-401	Bracket R; Drum Cover F	2	15,19	
011-12223-408	Bracket L; Drum Cover F	2	15,19	
011-12224-005	Drum Cover F (Lower)	2	15,19	
011-12241-007	Shaft Support II; Squeegee	2	15,19	
011-12311-005	Drum Catch (L)	1	25	
011-13122-109	Bracket; Magnet Catch; P. -Rcv.-T.	1	3	
011-13204-008	Pulley; Suction Motor	1	31	
011-13206-205	Suction Fan Cover	1	31	
011-13220-003	Transfer Belt	3	31	
011-13301-208	Lever; Separator	1	29	
011-13306-005	Collar A; Separator	2	29	
011-13307-206	Adj. Stopper; Separator	1	29	
011-13310-002	Hook Plate	2	29	
011-13311-106	Release Lever	1	29	
011-13916-008	Boss; JS Bracket	2	65	
011-14115-009	Linking Plate; M. -Rmv. Hook	1	51	
011-14121-106	Pulley B; M. -Rmv.	1	51	
011-14408-006	Bracket; Disposal Box SW	1	51	
011-14421-207	Guide Cam; Disposal Box	2	53	
011-14422-203	Guide Spring; Disposal Box	1	53	
011-14428-007	Lock Spring (Right)	1	53	
011-14429-003	Lock Spring (Left)	1	53	
011-15001-007	Support Shaft	2	45	
011-15004-006	Fulcrum; TPH	2	47	
011-15013-005	Open/Close Hook	2	47	
011-15037-109	Bracket; Loading Pulse Motor	1	27	
011-15098-000	Hook Spring	2	47	
011-15110-000	Pulley; Loading Roller (Lower)	1	45	
011-15117-005	Cam; Thermal Pressure Motor	1	47	
011-15146-102	Bracket; Write Pulse Motor	1	27	

Part No.	Part Name	Q'ty	Page	Unit Value
011-15708-208	Switch Cam	1	47	
011-17102-005	Magnet Catch Plate; Front	1	59	
011-17105-306	Front Left Cover	1	59	
011-17206-005	Bracket E; Keyboard	1	3	
011-17209-004	Set Plate; Front Right Cover	1	3	
011-17231-000	Set Plate Upper; Front Right Cover	1	3	
011-34502-009	Inner Cover; CE	1	3	
011-37211-005	Switch Box; CE	1	59	
011-60007-008	Rotation SW; A Position	1	59	
011-60020-004	Front Cover Set SW	1	59	
011-60027-106	Photoelectron Disc.	1	9	
011-65022-200	Counter	1	55	
011-70508-005	LCD; DMF5005N	1	63	
011-92106-008	Ass'y; Angular Magnet Plate	1	23	
011-93110-009	Magnet Catch Ass'y; P.-Rcv.-T.	1	3	
014-11114-100	Bottom Cover; A3; CE	1	3	
014-11301-202	Guide Roller; A3	1	13	
014-11303-205	Timing Roller; A3	1	13	
014-11404-206	Guide Cover; Pressure; A3	1	13	
014-11405-008	De-electricity Brush; A3	1	13	
014-11406-209	Pressure Roller Support; A3; CE	1	13	
014-11410-001	Support Collar; A3	2	13	
014-11502-003	Shaft A; P. -F. -T.	1	7	
014-11529-203	Feed Board Cover	1	7	
014-11533-006	Spring; Slide Rack	1	7	
014-12101-002	Drum Body; A3	1	23	
014-12103-005	Drum Body Support (Left); A3	1	23	
014-12114-007	Seal Tape; A3	1	23	
014-12115-003	Clamp Sub-Plate	1	23	
014-12116-301	Ink Blocking Sheet; A3	1	23	
014-12121-607	Sheet; Clamp Plate; A3	1	23	
014-12130-002	Drum Body; A4W	1	23	
014-12201-104	Squeegee Stay; A3	2	15,19	
014-12211-002	Inking Pump Body; A3	2	16,20	
014-12213-005	Ink Distributor; A3	2	16,20	
014-12216-101	Bottle Guide II Ass'y	1	15,19	
014-12217-000	Bottle Guide II (Base)	2	15,19	
014-12221-407	Squeegee Roller; A3	2	15,19	
014-12226-000	Doctor Roller II; A3	2	15,19	
014-12227-103	Reverse Rotation Stopper AII	2	15,19	
014-12251-004	Adj. Shaft; Squeegee; A3	2	15,19	
014-12252-000	Drive Shaft; Squeegee; A3	2	15,19	
014-12295-001	Lever; Bottle Stopper	2	15,19	
014-12297-004	Spring; Stopper Lever	2	15,19	
014-12301-109	Rail; Drum; A3	2	25	

Part No.	Part Name	Q'ty	Page	Unit Value
014-12310-108	Rail Bracket; Drum	1	25	
014-12311-007	Shaft; Lock	1	25	
014-12322-106	Lock Hook; Drum Lock	1	25	
014-12324-109	Bracket; Drum Lock	1	25	
014-12326-004	Spring; Lock	1	25	
014-13310-004	Nozzle (Lower); Separation	1	29	
014-13311-108	Nozzle (Upper); Separation	1	29	
014-13312-007	Bracket; Separation Fan	1	29	
014-14119-405	Front Cover; M.-Rmv.; A3; CE	1	3	
014-14465-001	Lock Shaft; Disposal Box; A3	1	53	
014-14469-007	Shaft; Disposal Box Cover; A3	1	53	
014-15007-007	Load Roller	1	47	
014-15008-003	Shaft; Open/Close Hook; A3	1	47	
014-15011-004	De-electricity Bar; M. -M.; A3	2	47	
014-15013-007	Sheet; Light Absorber; M. -M.	1	47	
014-15018-009	Catch Roller (Upper); A3	1	47	
014-15021-107	Fulcrum III; M. -M.; CE	2	47	
014-15028-004	Reinforce Shaft	1	47	
014-15102-000	Load Roller (Lower); M. -M.	1	45	
014-15116-205	Set Sheet E	2	49	
014-15144-209	Spring Hanger L; Master Guide Plate; CE	1	45	
014-15145-205	Spring Hanger R; Master Guide Plate; CE	1	45	
014-15146-007	Spring; Master Guide Plate	2	45	
014-15155-006	Mount; Loading Pulse Motor	1	27	
014-15182-003	Fixing Plate; Pulley G	1	45	
014-15191-100	Guide Plate; Load; A3	1	45	
014-15214-002	Set Plate; Cover	1	45	
014-17101-000	Back Cover; A3	1	59	
014-17207-100	Back Cover; Counter	1	55	
014-37203-004	Cover; Drum Lock; CE	1	25	
014-91320-008	Guide Roller Ass'y; A3	1	13	
014-91410-309	Pressure Shaft Ass'y; A3; CE	1	13	
014-91412-000	Pressure Shaft; A3	1	13	
014-91420-002	Pressure Roller Ass'y; A3	1	13	
014-92351-004	Unit/Drum Lock	1	25	
015-27128-001	Balance Weight; FB	4	43	
015-35223-102	Slide Base; P. -Rcv. -T.	3	33	
015-35225-300	Plate Spring; P. -Rcv. -T.	3	33	
015-35226-004	Slide Plate; P. -Rcv. -T.	3	33	
015-35244-304	Flap Adj. Plate; P. -Rcv. -T.	4	33	
015-35246-005	Adj. Lever; P. -Rcv. -T.	4	33	
015-58000-003	Image Flexible Wire	1	43	
015-71001-000	Image Scanner 600	1	43	
017-11201-200	Bracket A; Sensor	1	9	
017-11202-001	Bracket B; Sensor	2	9	

Part No.	Part Name	Q'ty	Page	Unit Value
017-11208-000	Base Shaft Plate; Pressure	1	10	
017-11209-108	Face Plate; Main Shaft	1	9	
017-11214-000	Pressure Link; Top	1	9	
017-11215-006	Pressure Link; Bottom	1	9	
017-11216-002	Link Boss A	1	9	
017-11217-009	Link Boss B	1	9	
017-11223-009	Linking Plate; Drive Base	1	9	
017-11224-005	Link Spacer	1	9	
017-11225-001	Spring; Pressure Link	1	9	
017-11227-004	Pressure Adj. Screw	1	9	
017-11229-007	Bracket; Pressure Control Motor	1	27	
017-11231-001	Bracket A; Pressure Control	1	9	
017-11232-202	Bracket B; Pressure Control	1	9	
017-11234-000	Spring; Linking Plate	1	9	
017-11240-108	Print Positioning Motor	1	27	
017-11516-103	Size Gear; P. -F. -T.	1	7	
017-11519-102	Lead SW Cover; P. -F. -T.; CE	1	7	
017-11602-301	Link Plate; Elevator	1	5	
017-11640-009	Bracket; Elevator Spring	1	5	
017-11648-000	Bracket; Lower Limit Sensor	1	5	
017-11649-006	Gear; Elevator	1	5	
017-11805-008	Bracket; P.-F. Pressure Adj. Lever	1	5	
017-11808-007	Hook; P.-F. Pressure Adj.	1	5	
017-11812-004	Shaft; Scraper	1	5	
017-11818-002	Scraper Collar	1	5	
017-11819-009	Spring F; Safety SW	1	5	
017-11820-007	Spring B; Safety SW	1	5	
017-12201-602	Frame; Drum	1	15,19	
017-12203-001	Bracket B; Connector; Drum	1	25	
017-12205-101	Position A Plate	1	23	
017-12211-004	Bracket; Stopper Lever	2	15,19	
017-12213-007	Inner Cover; Drum	2	15,19	
017-12215-107	PCB Cover; Drum	2	16,20	
017-12216-103	Drum Lever	2	15,19	
017-12409-009	Bracket; Angular Sensors	1	27	
017-12601-309	Drum Holder	1	25	
017-12604-103	Lever; Drum Holder	1	25	
017-12605-100	Lever Base; Drum Holder	1	25	
017-12606-009	Shaft; Drum Holder	1	25	
017-12607-005	Spring; Drum Holder	1	25	
017-13201-800	Face Cover W; Suction	1	31	
017-13205-202	Shaft; Jump Wing	2	31	
017-13208-007	Wing Plate; Suction	2	31	
017-13210-001	Spring; Belt Roller; Suction	1	31	
017-13211-008	Shaft Plate; Belt Roller; Suction	1	31	

Part No.	Part Name	Q'ty	Page	Unit Value
017-13216-000	Belt Roller; Suction	1	31	
017-13219-300	Suction Cover W (Upper)	1	31	
017-13220-104	Cover; Paper Rcv. Sensor 1	1	31	
017-13221-208	Cover; Paper Rcv. Sensor 2	1	31	
017-13222-107	Shaft; Wing Cam; Suction	1	31	
017-13223-006	Cam Gear; Suction	1	31	
017-13224-207	Wing Cam (F); Suction	1	31	
017-13225-106	Roller Cam; Suction	1	31	
017-13226-102	Wing Cam (R); Suction	1	31	
017-13228-105	SW Cam; Suction	1	31	
017-13229-209	Adj. SW Plate; Suction	1	31	
017-13232-102	Bracket; Suction Fan	1	31	
017-13233-001	Seal	1	31	
017-13235-004	Idler Shaft; Suction	1	31	
017-13236-205	Belt Idler; Suction	1	31	
017-13237-104	Fulcrum Plate II; Gear Pulley; Suction	1	31	
017-13239-000	Spring; Jump Wing (F)	1	31	
017-13240-008	Stay; Suction	1	31	
017-13241-004	Spring; Jump Wing (R)	1	31	
017-13242-000	Shaft Plate; Wing Gear	1	31	
017-13246-006	Wing Gear; Suction	1	31	
017-13247-002	Drive Shaft; Suction	1	31	
017-13248-009	Pulley; Wing Motor	1	31	
017-13252-006	Side Flap (F); Suction	1	31	
017-13255-005	Side Flap (R); Suction	1	31	
017-13257-008	Spring; Side Flap; Suction	2	31	
017-13258-004	De-electricity Brush; Suction	1	31	
017-13301-007	Release Lever; Separator	1	29	
017-13901-004	Positioning Bracket; JS III	1	65	
017-13902-000	Bracket; JS III	1	65	
017-14111-309	Sensor Bracket; M. -Rmv.	1	51	
017-14114-006	Set Collar; M. -Rmv.	2	51	
017-14115-002	Screw; M. -Rmv.	2	51	
017-14116-009	Fulcrum; Master Guide; M. -Rmv.	2	51	
017-14122-106	Bracket; M. -Rmv. Solenoid	1	51	
017-14159-107	H. -Lever (F); Disposal Box	1	53	
017-14161-101	H. -Lever (R); Disposal Box	1	53	
017-14163-007	Disposal Shaft	1	53	
017-14166-103	Compression Plate; Disposal Box	1	53	
017-14167-002	Guide Spring B; Disposal Box	1	53	
017-15009-001	Load Roller	2	47	
017-15213-008	Holder Stay R	1	45	
017-15214-004	Holder Stay F	1	45	
017-15306-006	Bracket; Master Positioning Sensor	1	49	
017-16021-005	Rack Cover; ADF Cover	1	59	

Part No.	Part Name	Q'ty	Page	Unit Value
017-16121-000	Bracket; Upper Cover Set SW	1	3	
017-16122-006	Shaft A; Upper Cover Set SW	1	3	
017-16123-002	Shaft B; Upper Cover Set SW	1	3	
017-16124-106	Spring; Upper Cover Set SW	1	3	
017-16530-007	Pulley A; ADF	2	37	
017-16538-008	Gear; ADF	1	37	
017-16542-005	Roller (Lower); ADF	3	35	
017-16546-000	De-electricity Brush B; ADF	1	37	
017-16555-000	Roller (Spring); ADF	3	35	
017-16562-006	Spring; Read Roller	2	37	
017-16588-005	Belt; 44	1	37	
017-16595-001	Mount; Read Pulse Motor	1	37	
017-17050-106	Bracket A; Keyboard	1	55	
017-17051-005	Bracket B; Keyboard	1	55	
017-17105-008	Slide Rack; Original Holder	2	59	
017-17210-103	Bottom Plate (Right)	1	3	
017-17217-205	Bottom Plate (Left); CE	1	3	
017-17220-109	Carrying Grasp	4	3	
017-17221-008	Mount; Connector	1	3	
017-17222-004	Blind Plate C; Connector	2	3	
017-17223-000	Blind Plate D; Connector	2	3	
017-17232-204	Side Cover; Power Supply	1	55	
017-21108-208	Bracket; Wire Harness	1	25	
017-22301-001	Bracket II; Drum Control PCB2	2	15,19	
017-23314-000	Bracket II; P. -Rcv. Sensor II (Receive)	1	29	
017-23405-307	Bracket D; Magnet Catch; P. -Rcv.-T.; CE	1	3	
017-24108-101	Bracket; Disposal Box Master Sensor	1	51	
017-24109-108	Actuator; M. -Rmv. Hook Sensor	1	51	
017-24110-009	Bracket; M. -Rmv. Hook Sensor	1	51	
017-24138-000	Guide Boss; M. -Rmv.	2	51	
017-24139-104	Knob; M. -Rmv.	2	51	
017-24140-005	Knob Shaft; M. -Rmv.	2	51	
017-24141-001	Lock Plate	2	51	
017-24148-200	Disposal Box Guide; CE	1	41	
017-24151-007	Guide Collar; Disposal Box Guide	2	41	
017-24152-100	Bracket F; Master Removal Fan	1	45	
017-24153-107	Bracket R; Master Removal Fan	1	45	
017-24154-103	Sensor Cover; Disposal Box Guide; CE	1	41	
017-37224-003	Mount II; Connector; CE	1	3	
017-44101-103	Right-Side Frame; M. -Rmv.; CE	1	51	
017-44104-102	Left-Side Frame; M. -Rmv.; CE	1	51	
017-44111-001	Set Plate F; M. -Rmv.; CE	1	51	
017-44112-008	Set Plate R; M. -Rmv.; CE	1	51	
017-44113-004	Fixing Plate F; M. -Rmv.; CE	1	51	
017-44114-000	Fixing Plate R; M. -Rmv.; CE	1	51	

Part No.	Part Name	Q'ty	Page	Unit Value
017-51032-001	ADF PCB	1	37	
017-55017-007	Wire Harness; Motor Con.-System	1	57	
017-55028-106	Wire Harness; Drum (R)	2	15,19	
017-55029-005	Wire Harness; Drum (L)	2	15,19	
017-55031-204	Wire Harness; Elevator Motor	1	57	
017-55039-108	Wire Harness; Guide Plate; 49	1	13	
017-55049-006	Wire Harness; RA-RC Sorter Inner	1	65	
017-55054-000	Inner COM Wire Harness; SF	1	65	
017-55062-002	Wire Harness; EXE-I/F	1	65	
017-60001-208	Master Removal Sensor	1	51	
017-60003-006	Paper Sensor	1	13	
017-60007-001	Upper Limit Sensor	1	5	
017-60010-002	Switch A	1	51	
017-60016-000	Angular Sensor	1	27	
017-60020-300	Drum PCB	2	16,20	
017-60025-000	Micro-SW Ass'y 3	1	5	
017-60031-000	Encoder Sensor	1	9	
017-60037-105	Master Sensor II	1	51	
017-65003-004	M. -Rmv. Vertical Transport Motor	1	51	
017-65005-309	Pressure Control Motor	1	27	
017-65006-003	Wing Motor; Suction	1	31	
017-65011-007	Loading Fan; Stocker	1	45	
017-65015-207	Loading Pulse Motor	1	27	
017-65016-602	Inking Motor	2	16,20	
017-91206-002	Pressure Det. Ass'y	1	9	
017-91240-103	Unit/Print Positioning Motor	1	27	
017-91266-005	Pressure Control Motor Ass'y	1	27	
017-91620-003	Unit/Elevator Motor	1	5	
017-92300-002	Unit/Drum Frame	1	15,19	
017-93110-100	Magnet Catch Ass'y D; P. -Rcv.-T.; CE	1	3	
017-93220-002	Angular Sensor Ass'y	1	27	
017-95050-007	Unit/Loading Pulse Motor	1	27	
017-97300-108	Wire Harness; JS III; CE	1	65	
018-16017-005	Drive Pulley Shaft; FB-Scanner	1	43	
018-16019-008	Belt Stand Plate; FB-Scanner	1	43	
018-16020-006	Belt Holder Plate; FB-Scanner	1	43	
018-16022-009	Tension Shaft; FB-Scanner	1	43	
018-16023-005	Tension Holder; FB-Scanner	1	43	
018-16024-001	Tension Plate; FB-Scanner	1	43	
018-16027-000	Tension Spring; FB-Scanner	1	43	
018-16031-105	Bracket; FB-Pos. Sensor	2	41	
018-16032-101	Actuator Stage Cover Sensor	1	41	
018-16035-003	Actuator Spring; Stage Cover Sensor	1	41	
018-16039-106	Glass Holder (R)	1	41	
018-16064-003	Blind Plate; FB-Back Frame	1	41	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16067-207	Shading Plate (R)	2	41	
018-16071-000	Protection Tape; Stage Glass	2	41	
018-16073-002	Shock-Absorbent Rubber	1	41	
018-16202-007	Stepped Screw; M6 x 10	2	3	
018-16218-000	Shaft; Hook Base	2	41	
018-16220-200	Hook Base (F); FB-Hook Shaft	1	41	
018-16222-105	Hook Base (R); FB-Hook Shaft	1	41	
018-16223-004	Spring; Hook Shaft	2	41	
018-16229-100	Hook Plate (F): FB; CE	1	3	
018-16239-105	Bracket B; Interlock Switch FB	1	55	
018-16241-100	Bracket; Damper Stopper; CE	1	3	
018-16242-009	Spring; Damper Stopper	1	3	
018-16243-102	Cap; Damper Stopper	1	3	
018-16250-206	Damper Hook; FB-Scanner; CE	2	41	
018-16254-007	Plate Spring; Interlock Switch FB	1	55	
018-16305-507	Cover B; FB-ADF	1	35	
018-16309-200	Original Tray; FB	1	59	
018-16310-101	Original Side Guide	2	59	
018-16312-007	Shaft; Original Tray	2	59	
018-16401-204	Stage Cover; FB	1	61	
018-16403-100	LCD Cover; Digitizer	1	63	
018-16406-206	PCB Cover; Stage Cover	2	61,63	
018-16411-102	Original Holder Cover (Upper); Stage Cover	1	61	
018-16412-400	Original Holder Cover (Lower); Stage Cover	1	61	
018-16413-008	Cover B; Stage Cover	1	61	
018-16415-701	Balance Weight A; Stage Cover	1	61	
018-16416-104	Balance Weight B; Stage Cover	1	61	
018-16417-100	Balance Weight C; Stage Cover	1	61	
018-16418-000	Cord Cap; Stage Cover	1	61	
018-16420-004	Actuator Plate; Stage Cover	2	61,63	
018-16425-006	Stage Pad (W); Stage Cover	2	61,63	
018-16427-203	Stylus Pen III	1	63	
018-16431-006	LCD Filter; Digitizer	1	63	
018-16435-001	LCD Cover; Digitizer; CE	1	63	
018-16502-108	Glass Plate; Image Scanner	1	35	
018-16503-104	Main Gear; FB-ADF	1	37	
018-16504-003	Stepped Screw; M4 x 13	1	37	
018-16506-006	Stopper Plate; FB-ADF	1	37	
018-16507-100	Tension Plate; FB-ADF	1	37	
018-16508-203	Side Frame L; FB-ADF	1	35	
018-16510-003	Tension Pulley B; FB-ADF	1	37	
018-16513-002	Transfer Roller; FB-ADF	1	37	
018-16514-009	Exit Roller (Upper); FB-ADF	1	37	
018-16516-109	Read Roller	1	37	
018-16518-101	Motor Cover; FB-ADF	1	37	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16522-001	Bracket; ADF Motor	1	37	
018-16526-007	Spacer; WHG	1	37	
018-16532-007	Open Lever; FB-ADF	1	37	
018-16533-100	Glass Holder R; Image Scanner	1	35	
018-16534-107	Glass Holder L; Image Scanner	1	35	
018-16535-103	Bracket; Original Out Sensor	1	37	
018-16536-002	Bracket; Original Det. Sensor	1	37	
018-16537-009	Bracket; Original Regist. Sensor	1	37	
018-16541-006	Collar; Stripper Roller	1	37	
018-16543-009	Tension Pulley A; FB-ADF	2	37	
018-16544-005	Pulley; Read Roller	1	37	
018-16545-001	Exit Pulley; FB-ADF	1	37	
018-16546-008	Spacer; Main Gear; FB-ADF	1	37	
018-16547-004	Metal; 8P	2	37	
018-16548-000	Metal; 8M	5	35,37	
018-16549-007	Housing; Exit Roller	2	37	
018-16550-102	Housing; Read Roller	2	37	
018-16551-001	Metal; 6	2	37	
018-16552-008	Spacer; Exit Roller	1	37	
018-16554-000	Metal; Exit Roller	1	35	
018-16555-007	De-electricity Brush A; FB-ADF	2	37	
018-16558-006	Spring R; FB-ADF	1	37	
018-16559-002	Spring L; FB-ADF	1	37	
018-16561-104	ADF Motor; FB	1	37	
018-16563-000	Read Pulse Motor; FB-ADF	1	37	
018-16564-006	Original Det. Sensor	1	37	
018-16565-002	Original Regist. Sensor	1	37	
018-16566-009	Original Out Sensor	1	37	
018-16567-005	Original IN Sensor (Send)	1	37	
018-16568-001	Original IN Sensor (Receive); FB-ADF	1	35	
018-16569-008	Wire Harness; Original IN Sensor	1	35	
018-16570-006	ADF SW; FB	1	35	
018-16571-002	Wire Harness; FB-ADF SW	1	35	
018-16572-009	Belt B; 56	1	37	
018-16575-008	Collar; Pickup Roller; FB-ADF	1	37	
018-16577-000	Bushing; FB-ADF	3	37	
018-16578-201	Free Bushing	1	35	
018-16580-001	Spacer; Stripper; FB-ADF	1	35	
018-16581-008	Bushing (1); ADF Motor	1	37	
018-16582-004	Bushing (2); ADF Motor	1	37	
018-16583-000	Bushing (3); ADF Motor	1	37	
018-16585-003	Belt; 118	1	37	
018-16590-104	Roller Spring II; ADF	2	35	
018-16591-003	Guide Plate; FB-ADF	1	37	
018-16592-000	Original Guide Base (R); FB-ADF	1	35	

Part No.	Part Name	Q'ty	Page	Unit Value
018-16593-006	Exit Wheel; ADF; FB	2	35	
018-16598-105	Bracket; ADF SW	1	35	
018-16600-002	Actuator; ADF SW	1	35	
018-36227-103	Bracket (R); Hook Shaft	1	41	
018-51004-803	Digitizer PCB III	1	63	
018-55001-108	Wire Harness; FB	1	41	
018-55015-001	Wire Harness; Digitizer III ; CE	2	63,65	
018-55016-008	Wire Harness; Image-Digitizer; CE	2	57,65	
018-60000-101	Original Det. Sensor; FB	1	43	
018-65000-002	R Pulse Motor; FB	1	41	
018-70017-002	INF ROM (OP); Digitizer	1	63	
018-70018-009	INF ROM (ST); Digitizer	1	63	
018-70019-005	INF ROM (OP1); Digitizer	1	63	
018-70020-003	INF ROM (OP2); Digitizer	1	63	
018-96200-115	Unit/Stage Cover	1	61	
018-96210-005	Stage Cover Hinge Ass'y	2	61	
018-96230-200	Ass'y/Digitizer Stage Cover; FB; CE	1	63	
018-96600-008	Original Tray Ass'y; FB	1	59	
019-11201-000	Idler Pulley	4	9	
019-11209-000	Slide Plate (Base)	1	9	
019-11213-008	Base Plate; P. -F. Clutch	1	9	
019-11214-004	Bracket; Print Positioning Motor	1	27	
019-11220-101	Bracket; P. -F. Clutch; CE	1	9	
019-11222-007	Cover; Paper Feed Clutch; CE	1	10	
019-11223-003	Spring; Pressure Link	1	10	
019-11224-000	Face Plate; Pressure Shaft	1	9	
019-11225-006	Resting Position Plate; Pressure Lever	1	9	
019-11226-002	Hook Lever	1	9	
019-11230-000	Spring; Hook Lever	1	9	
019-11231-103	Shaft; Hook Lever	1	9	
019-11235-001	P Disc	1	9	
019-11238-000	Range Adj. Plate; P Disc	1	9	
019-11240-102	Pressure Lever	1	9	
019-11501-208	Bracket; Ground Finger	2	3	
019-11502-000	Connector Cover	1	7	
019-11520-105	Support Plate R; Feed Board; CE	1	7	
019-11521-101	Support Plate L; Feed Board; CE	1	7	
019-11522-108	Link Plate; Side Guide; P. -F. -T.	2	7	
019-11524-100	Slide Sheet; P. -F. -T.	4	7	
019-11702-009	Sheet; Guide Plate	1	13	
019-11731-009	Stripper Sheet (SHRT); 80	1	13	
019-11733-109	Base; Stripper Sheet	1	13	
019-11734-202	Cover (STND); Stripper Sheet	1	13	
019-11737-104	Shaft; Stripper (Dial)	1	13	
019-11738-003	Spring; Stripper (Dial)	1	13	

Part No.	Part Name	Q'ty	Page	Unit Value
019-11739-000	Adj. Dial; Stripper	2	13	
019-11740-105	Spring Stopper; Stripper (Dial)	1	13	
019-11741-101	Bracket; Stripper Shaft (Dial)	1	13	
019-11742-108	Housing; Stripper (Dial)	1	13	
019-11744-003	Bracket; Stripper Unit (Dial)	1	13	
019-11748-009	Bracket; Stripper Base (Dial)	1	13	
019-11749-102	Actuator Plate II; Stack P.-F. SW	1	13	
019-11750-100	Worm Gear Box; Stripper (Dial)	1	13	
019-11755-005	Bracket II; Stack Paper Feed SW	1	13	
019-11756-001	Spring; Stack Paper Feed SW	1	13	
019-11760-106	Cam Plate; Stripper (Dial)	1	13	
019-11801-104	Holder Plate; Scraper; CE	1	5	
019-11803-000	Upper Arm; Scraper	1	5	
019-11804-006	Spring; Scraper	1	5	
019-11806-106	Rubber Roller; Pickup	2	5	
019-11810-103	Pickup Roller Ass'y	2	5	
019-11811-100	Spring B; P.-F. Pressure Adj.	1	5	
019-11812-106	Lock Ring	4	5	
019-11814-206	Bracket; Upper Limit Sensor	1	5	
019-12206-005	Adj. Plate (Front); Squeegee	2	15,19	
019-12207-001	Adj. Plate (Back); Squeegee	2	15,19	
019-12208-008	Spacer; 18 x 10 x 1.8	4	15,19	
019-12209-004	Holder; Bottle SW	1	20	
019-12210-002	Set Plate; Bottle SW	2	16,20	
019-12211-009	Spring; Bottle SW	1	20	
019-12214-008	Position C2 Plate	1	23	
019-12215-004	Position C1 Plate	1	23	
019-12223-007	Bracket A; Connector; Drum	1	25	
019-12301-008	Rail B; Drum	1	25	
019-12302-101	Drum Cover (Upper)	1	20	
019-12303-108	Drum Cover (Lower)	1	20	
019-12304-007	Guide Block; Drum Holder	1	25	
019-12307-006	Spring; Locking Plate; Drum	2	15,19	
019-12308-002	Drum Catch (R) II	1	25	
019-12314-002	Locking Plate II; Drum	2	15,19	
019-12315-009	Shaft; Locking Plate II; Drum	2	15,19	
019-13102-009	Paper Guide F; P. -Rcv. -T.	1	33	
019-13103-005	Paper Guide R; P. -Rcv. -T.	1	33	
019-13112-004	Reinforce Plate; P. -Rcv. -T.	2	33	
019-13113-108	Back Stop; P. -Rcv. -T.	1	33	
019-13115-208	Flap; P. -Rcv. -T.	16	33	
019-13116-107	Flap Cover; P. -Rcv. -T.	4	33	
019-13119-009	Lock Plate; P. -Rcv.-T.	2	3	
019-13125-106	Receiving Tray Plate	1	33	
019-13126-005	Frame; P. -Rcv. -T.	1	33	

Part No.	Part Name	Q'ty	Page	Unit Value
019-13130-002	Ground Plate; P. -Rcv. -T.	1	33	
019-13131-106	Slide Rail A; P. -Rcv. -T.	1	33	
019-13132-102	Slide Rail B; P. -Rcv. -T.	2	33	
019-13133-109	Catch Plate; P. -Rcv. -T.	1	33	
019-13137-007	Jump Wing (F); Suction; A3	1	31	
019-13138-003	Jump Wing (R); Suction; A3	1	31	
019-13143-007	Job Separator Bracket EX	1	65	
019-13203-000	Gear Pulley 38; Suction	1	31	
019-13301-109	Separator II	1	29	
019-13501-000	Cylinder; Air Pump	1	29	
019-13503-003	Cam Pulley; Air Pump	1	29	
019-13504-000	Cam Plate; Air Pump	1	29	
019-13507-106	Bracket; Air Pump	1	29	
019-13511-103	Arm; Air Pump	1	29	
019-13512-002	Arm Shaft; Air Pump	1	29	
019-13514-005	Air Hose; Separator	1	29	
019-13516-105	Piston Head II; Air Pump	1	29	
019-13517-004	Cylinder Valve II; Air Pump	1	29	
019-13518-000	Cylinder Valve Sheet; Air Pump	1	29	
019-13601-200	Gear A; Clutch	1	27	
019-13602-001	Gear B; Clutch	1	27	
019-13603-105	Drive Gear; Clutch	1	27	
019-13604-004	Idler Gear; Clutch	1	27	
019-13610-209	Bracket; Tension Pulley	1	10	
019-14231-007	Hinge Reinforcement; Disposal Box	1	53	
019-15125-006	Base Plate; Write Pulse Motor	1	27	
019-15253-004	Damper Gear	1	45	
019-15254-000	Shaft Flange; Master Holder	1	45	
019-15255-007	Stopper; Guide Flange	1	45	
019-15270-006	Damper Case	1	45	
019-15273-005	Spring; Master Holder	1	45	
019-16066-003	Cap I; CE	1	41	
019-16067-000	Cap 2; CE	1	3	
019-16214-100	Shaft; Damper Bottom Bracket	2	41	
019-16215-009	Damper Bottom Bracket	2	41	
019-16236-103	Bracket; Interlock Switch FB	1	55	
019-17008-007	Mylar Sheet; Panel SW	1	55	
019-17009-100	Sheet B; Panel	1	55	
019-17010-109	Sheet A; Panel	2	55	
019-17011-008	Door; Panel	1	55	
019-17090-307	Reinforce Plate; Panel; CE	1	55	
019-17099-002	Grand Plate; Panel	1	55	
019-17101-104	Front Cover	1	59	
019-17104-308	Front Right Cover	1	59	
019-17202-008	Upper Hinge	1	3	

Part No.	Part Name	Q'ty	Page	Unit Value
019-17205-007	Bracket C; Keyboard	1	3	
019-17206-003	Bracket D; Keyboard	1	3	
019-17215-002	Lower Hinge; Front	1	59	
019-17236-204	Bracket; Motor Control PCB	1	57	
019-17241-305	Shaft Stopper; Damper; CE	1	41	
019-17242-107	Bracket; Power Supply Fan	1	55	
019-17251-203	Lock Plate; Support Shaft	1	3	
019-17252-307	Hook Plate (R): FB; CE	1	3	
019-17255-004	Support Shaft Lock	1	41	
019-18051-100	Guide; Motor Wire Harness; CE	1	10	
019-18121-001	Cover Plate; Power Supply	1	55	
019-18129-002	Bracket E; Option PCB; CE	1	57	
019-18130-000	Bracket F; Option PCB; CE	1	57	
019-21201-105	Cam; Pressure Roller; A3	1	9	
019-21202-004	Spring C; Pressure Link	1	9	
019-21301-002	Shaft; Timing Roller	1	13	
019-21302-009	Bracket; Timing Roller	1	13	
019-21501-001	Shaft B; P. -F. -T.	1	7	
019-21512-100	Slide Rack F; P. -F. -T.; CE	1	7	
019-21513-107	Slide Rack; P. -F. -T.; CE	1	7	
019-21514-308	Actuater Plate; P. -F. -T.; CE	1	7	
019-21518-109	Bracket; Size VR; P. -F. -T.; CE	1	7	
019-21602-002	Spring; Elevator	2	5	
019-21716-008	Guide Plate (Upper)	1	13	
019-21717-004	Guide Plate (Lower)	1	13	
019-21802-109	Bracket; Feed Tray Safety SW; CE	1	5	
019-21805-108	Shaft; Pickup Roller	1	5	
019-22101-104	Drum Body Support (Right); A3	1	23	
019-22102-305	Screen Ass'y; A3	1	23	
019-22106-106	Screen Hanger(Lower)	1	23	
019-22107-102	Spring; Screen	2	23	
019-22108-206	Clamp Plate Base	1	23	
019-22111-002	Clamp Magnet A; A3	1	23	
019-22112-106	Light Absorber Strip; A3	1	23	
019-22113-102	Anti-Wrinkle Strip; Drum	1	23	
019-22203-209	Bracket; Bottle SW	1	20	
019-22206-003	Reverse Rotation Stopper B	2	15,19	
019-23204-004	Bracket F; Suction; A3	1	3	
019-23205-108	Bracket R; Suction; A3	1	3	
019-23301-107	Shaft; Separator II; A3; CE	1	29	
019-23401-209	Set Plate F; P. -Rcv.-T.; A3	1	3	
019-23403-201	Set Plate R; P. -Rcv.-T.; A3	1	3	
019-23601-208	Bracket; Suction Drive; A3	1	27	
019-23604-304	Shaft; Clutch; A3	1	27	
019-23605-505	Clutch Cover; A3	1	27	

Part No.	Part Name	Q'ty	Page	Unit Value
019-24101-004	Stay A; M. -Rmv.	1	51	
019-24104-208	Guide Plate; M. -Rmv.; A3; CE	1	51	
019-24105-000	Vertical Transport Roller (Down); A3	1	51	
019-24107-002	Shaft; M. -Rmv. Hook; A3	1	51	
019-24110-100	Master Guide; M. -Rmv.; A3	1	51	
019-24111-000	Guide Plate; M. -Rmv.; A3	1	51	
019-24119-108	Vertical Transport Roller (UP); A3	1	51	
019-24126-104	Bracket; Aero Guide Sheet; CE	1	45	
019-24127-100	Aero Guide Sheet; A3	1	45	
019-24132-104	Disposal Box Cover; A3	1	53	
019-24133-003	Disposal Box Cover B; A3	1	53	
019-24134-000	Guide Plate; Disposal Box; A3	1	53	
019-24135-006	Lever Frame; Disposal Box; A3	1	53	
019-24137-009	Guide Shaft; Disposal Box; A3	1	53	
019-24138-005	Shaft; Compression Plate; A3	1	53	
019-25006-307	Bracket; Wire Harness; CE	1	3	
019-25007-001	Shaft; Load Roller	1	47	
019-25101-105	De-electricity Brush	1	45	
019-25103-000	Protection Sheet; De-electricity Brush	1	45	
019-25111-003	Stocker	1	45	
019-25112-107	Stocker Cover	1	45	
019-25115-009	Set Sheet Plate; A3	1	49	
019-25116-005	Set Sheet	2	49	
019-25301-309	Cutter Cover	1	49	
019-25305-002	Master Guide Stopper Plate	1	49	
019-25306-009	Master Guide Stopper Cushion	1	49	
019-25307-102	Cutter Guide	1	49	
019-25309-008	Gear; Cutter Motor	1	49	
019-25311-100	Cutter Guide Sheet (A3)	2	49	
019-25312-300	Cutter Center Guide Sheet	1	49	
019-25511-001	Spring; TPH Pressure	2	47	
019-25516-100	Set Guide Shaft	1	45	
019-25517-000	Stay R; Set Guide Plate	1	45	
019-25518-006	Stay L; Set Guide Plate	1	45	
019-25519-002	Set Guide Plate; A3	1	45	
019-25527-200	Bracket; Micro-SW; M.-M.	1	45	
019-25531-002	Spring (Left); M. -M.	1	47	
019-25532-009	Spring (Right); M. -M.	1	47	
019-25533-005	Actuator Plate; Micro-SW	1	45	
019-25602-007	Base Plate F; Tension Roller	1	45	
019-25603-003	Base Plate R; Tension Roller	1	45	
019-25604-000	Torque Limiter; Tension Roller	1	45	
019-25605-006	Copy Guide Plate (Lower)	1	47	
019-25608-005	Base A; Nip Roller	1	47	
019-25609-001	Base B; Nip Roller	1	47	

Part No.	Part Name	Q'ty	Page	Unit Value
019-25610-000	Nip Roller	1	47	
019-25612-002	Bracket; Micro-SW	1	47	
019-26201-006	Fulcrum Shaft; FB	1	3	
019-26202-800	Bottom Plate; FB-Scanner; CE	1	41	
019-26214-000	Hook Shaft; FB; A3	1	41	
019-26217-000	Bracket; Back Cover; CE	1	3	
019-26218-103	Upper Rear Frame; FB; CE	1	3	
019-27231-006	Mole; 3770	1	59	
019-27240-102	Shaft; Damper	1	41	
019-27301-004	Protection Plate; Motor Con.	1	57	
019-32201-000	Spring; Bottle SW	1	16	
019-32202-103	Bracket; Bottle SW	1	16	
019-32203-207	Holder; Bottle SW	1	16	
019-32206-001	Elbow; Ink Distributor	2	16	
019-32302-000	Drum Cover (Upper)	1	16	
019-32303-007	Drum Cover (Lower)	1	16	
019-32401-009	Spring A; Clamp	1	27	
019-32402-102	Spring B; Clamp	2	27	
019-32403-001	Base Plate; Clamp	1	27	
019-32404-105	Cam; Clamp	1	27	
019-32405-101	Drive Gear; Clamp	1	27	
019-32406-000	Shaft; Clamp	1	27	
019-32407-201	Guide Plate; Clamp Cam	1	27	
019-32410-008	Frame; Clamp	1	27	
019-32411-004	Compensator Plate	1	27	
019-32412-000	Stopper Plate; Clamp	1	27	
019-32416-006	Plate Spring; Clamp	1	27	
019-32417-304	Clamp Plate Ass'y; II	1	23	
019-35002-105	Frame A; M. -M.	1	47	
019-35006-003	Bracket; TPH; A3	1	47	
019-35007-000	Cover A; M. -M.	1	47	
019-35008-006	Bracket; De-electricity Brush	1	45	
019-35015-100	Bracket; Pressure Assist Plate; CE	2	47	
019-35016-009	Pressure Assist Plate	2	47	
019-35020-006	Pulley; Write Pulse Motor	1	27	
019-35021-002	Pulley G; 600	1	45	
019-35022-009	Inner Cover A	1	59	
019-35024-109	Master Guide Plate; A3	1	45	
019-35028-007	Master Roll Holder	1	45	
019-35032-004	Guide Holder D; Master Holder	1	45	
019-35033-000	Cover; Master Roll Holder	1	45	
019-35035-003	Flange F; Master Roll	1	45	
019-35036-000	Flange R; Master Roll	1	45	
019-35037-006	Actuator Plate; Micro-SW; M. -M.	1	47	
019-36001-005	Slide Guide; FB-Scanner	1	43	

Part No.	Part Name	Q'ty	Page	Unit Value
019-36002-109	Main Frame; FB-Scanner	1	41	
019-36006-104	Stage Glass	1	41	
019-36007-003	Glass Plate; Scanner	1	41	
019-36008-000	Original Stopper	1	41	
019-36009-006	Glass Holder F; Scanner	1	41	
019-36010-004	Glass Holder R; Scanner	1	41	
019-36011-000	Drive Pulley Holder; FB-Scanner	1	43	
019-36013-003	Slide Shaft; FB-Scanner	2	43	
019-36014-000	Adj. Plate; FB-Slide Shaft	2	43	
019-36015-006	Hinge Bracket; FB-Scanner; CE	2	41	
019-36016-200	Wire Stand; FB-Image	1	43	
019-36017-009	Core Holder	1	43	
019-36018-102	Image Scanner Cover B	1	43	
019-36019-109	Image Scanner Cover S	1	43	
019-36020-000	Bracket; Stage Cover Sensor	1	41	
019-36022-002	Bracket; R Pulse Motor	1	41	
019-36023-009	Hook Plate; Scanner	1	41	
019-36025-109	Back Frame; FB-Scanner	1	41	
019-36026-008	Set Sheet A; Stage Glass	1	41	
019-36027-004	Set Sheet B; Stage Glass	1	41	
019-36028-000	Core Holder CE	1	43	
019-36029-007	Core Cover	1	43	
019-36201-004	Open Lever; Hook Shaft	1	41	
019-36202-108	Bracket (F); Hook Shaft	1	41	
019-36203-007	Fulcrum Plate; FB-Hook Shaft	1	41	
019-36206-006	Link Plate; FB-Hook Shaft	1	41	
019-36207-002	Bracket; Open Lever	1	41	
019-36301-106	Scanner Cover (F); FB	1	59	
019-36302-005	Scanner Cover (R); FB	1	59	
019-36303-001	Scanner Cover (Left); FB	1	59	
019-36304-008	Scanner Cover (Right); FB	1	59	
019-36305-004	Scanner Cover (LR)	1	59	
019-36306-000	ADF Cover (F); FB	1	59	
019-36307-007	ADF Cover (R); FB	1	59	
019-36308-003	ADF Cover (Right); FB	1	59	
019-36501-000	Pickup Roller Frame; FB-ADF	1	37	
019-36502-004	Bracket; Pickup Solenoid	1	38	
019-36503-000	Lever Shutter R	1	38	
019-36504-007	Lever Shutter L	1	38	
019-36505-003	Claw L; FB-ADF	1	38	
019-36506-000	Claw R; FB-ADF	1	38	
019-36507-006	Lever; Pickup	1	38	
019-36509-009	Shaft; Stripper Roller	1	35	
019-36510-007	Link; Pickup Solenoid	1	38	
019-36511-003	Lever; Hook Plate	1	37	

Part No.	Part Name	Q'ty	Page	Unit Value
019-36512-000	Plate; Hook Plate	1	37	
019-36514-002	Spring; Pickup Solenoid	1	38	
019-36515-009	Guide; Belt	1	35	
019-36516-005	Sheet; Original Guide Base	1	35	
019-36517-001	Spring Plate; FB-ADF	1	35	
019-36518-008	Stripper Tray; FB-ADF	1	35	
019-36519-004	Tray Spring; FB-ADF	1	35	
019-36520-002	Stripper Pad; FB-ADF	1	35	
019-36521-009	Sheet Guide; FB-ADF	3	37	
019-36522-005	Spacer; Transfer Roller	1	37	
019-36523-001	Collar; Transfer Roller	1	38	
019-36524-008	Tray Push; FB-ADF	1	35	
019-36526-000	Original Guide Base (F); FB-ADF	1	35	
019-36527-007	Original Guide (F); FB-ADF	1	37	
019-36528-003	Hook Plate; FB-ADF	1	37	
019-36529-000	Upper Frame; FB-ADF	1	37	
019-36530-008	Side Frame R; FB-ADF	1	35	
019-36531-004	Pickup Roller (Upper); FB-ADF	1	37	
019-36532-000	Shaft; Stripper Roller; FB-ADF	1	37	
019-36533-007	Frame B; FB-Original Guide	1	35	
019-36534-003	Stripper Arm; FB-ADF	1	35	
019-36535-000	Spring; Stripper Arm	1	35	
019-36536-006	Stripper Roller; FB-ADF	1	35,37	
019-36537-002	Stripper Shaft; FB-ADF	1	35	
019-36538-009	Pickup Solenoid; FB-ADF	1	38	
019-36539-005	Pulley; Transfer Roller	1	37	
019-36540-003	Spring; Open Lever	2	37	
019-37209-203	Bracket; Counter; En; CE	1	55	
019-37210-201	Bracket; Counter; Pic.; CE	1	55	
019-37212-000	Bracket; Hinge; CE	1	3	
019-38101-007	Bracket (R); System PCB	1	57	
019-38102-003	Bracket (L); System PCB	1	57	
019-38103-000	Cover (U); PCB	1	57	
019-38104-006	Cover (L); PCB	1	57	
019-38107-005	Bracket; Image PCB	1	57	
019-41502-209	Paper Feed Tray; CE	1	7	
019-41503-205	Paper Feed Tray; US; CE	1	7	
019-41517-001	Bracket; P. -F. -T.; CE	1	7	
019-41519-004	Feed Board; CE	1	7	
019-41801-109	Cover; Pickup Roller; CE	1	5	
019-43201-206	Cover Plate II; Suction; CE	1	31	
019-44102-007	Stay B; M. -Rmv.; CE	1	51	
019-44103-003	Base Plate; M. -Rmv; A3; CE	1	51	
019-44108-102	Upper Stay; M. -Rmv.; CE	1	51	
019-44112-002	Upper Holder B; V. - Transport Roller; A3; CE	1	51	

Part No.	Part Name	Q'ty	Page	Unit Value
019-44116-105	Upper Holder A; V. - Transport Roller; A3; CE	1	51	
019-44131-007	Disposal Box; A3; CE	1	53	
019-46205-008	Fulcrum Support Plate; FB; CE	1	3	
019-51000-503	System PCB 2	1	57	
019-51002-107	LCD CTL PCB	1	55	
019-51003-103	Main SW PCB; Panel	1	55	
019-51005-106	Drum Control PCB2	2	15,19	
019-51030-003	De-electricity PCB	1	57	
019-51040-106	Motor Control PCB2	1	57	
019-51041-102	Power Supply PCB VIII H100	1	55	
019-51042-001	Power Supply PCB VIII H200	1	55	
019-51043-059	Sub-Power Supply PCB	1	47	
019-51044-101	Image Processing PCB; IPIF	1	57	
019-51047-003	Option PCB A III	1	57	
019-55004-104	Wire Harness; Master Loading Unit SW	1	45	
019-55005-003	Wire Harness; M. -Rmv.	1	51	
019-55010-104	Wire Harness; Drum Inner	2	15,19	
019-55014-509	Wire Harness; CN9	1	57	
019-55015-009	Wire Harness J; Guide Plate	1	13	
019-55016-307	Wire Harness II; P. -F. -T.	1	7	
019-55024-105	Wire Harness; Disposal Box Master Sensor	1	41	
019-55025-004	Inlet Terminal; 100V	2	55,57	
019-55028-003	Wire Harness; CN15	2	25,57	
019-55032-000	Wire Harness; Feed Tray Safety SW	1	5	
019-55036-103	Wire Harness; Suction	1	31	
019-55037-002	Wire Harness; Removal Guide	1	41	
019-55066-100	Wire Harness; CN7; CE	1	57	
019-55074-102	Wire Harness II; Counter III; CE	1	65	
019-55077-004	Wire Harness; Panel-System; CE	1	57	
019-55078-000	Wire Harness; CN14; CE	2	55,57	
019-55079-007	Inlet Terminal; 200V; CE	2	55,57	
019-55087-000	Wire Harness; Image-FBI	2	41,57	
019-55088-006	Wire Harness; Image-FBI Power	2	41,57	
019-55089-100	Wire Harness; M. -M. - Image	2	47,57	
019-55090-000	Wire Harness; TPH Power	1	47	
019-55091-104	Wire Harness; Power	2	55,57	
019-55092-100	Wire Harness; TPH Power	2	47,55	
019-55094-006	Wire Harness; ADF (FB)	1	37	
019-55095-002	Wire Harness; CN9; CE	1	57	
019-55096-009	Wire Harness; CN15; CE	2	25,57	
019-55097-105	Wire Harness; Image-FBI Power; CE	2	41,57	
019-55098-001	Wire Harness; M. -M. - Image; CE	1	47,57	
019-55099-105	Wire Harness; Power; CE	2	55,57	
019-60000-001	Disposal Box Master Sensor	1	41	
019-60001-008	Disposal Box Master Sensor (Rcv.)	1	51	

Part No.	Part Name	Q'ty	Page	Unit Value
019-60010-309	Bottle Set SW	2	16,20	
019-60012-204	Paper Receiving Sensor (Send) IV	1	31	
019-60013-200	Paper Receiving Sensor IV (Receive)	1	29	
019-60014-002	Switch A; CE	1	3	
019-60015-106	Master End Sensor (Send)	1	45	
019-60019-101	Master Positioning Sensor II	1	49	
019-60020-002	Micro Sw Ass'y 4 (Stack)	1	13	
019-60022-005	Master End Sensor (Receive)	1	47	
019-60023-001	Bottle Set SW II	1	16	
019-60024-008	Image Scanner 600 CE	1	43	
019-65001-006	P. -F. Clutch	1	9	
019-65003-009	Fan; Power Supply	1	55	
019-65005-001	Master Removal Fan	2	45	
019-65006-008	Separation Fan	1	29	
019-65007-101	Suction Clutch	1	27	
019-65008-205	Cutter Motor Ass'y; CE	1	49	
019-65010-102	Suction Fan Ass'y; CE	1	31	
019-65012-008	Pressure Solenoid	1	9	
019-65014-000	Lock Solenoid	1	25	
019-65015-007	Master Removal Solenoid	1	51	
019-65016-100	Thermal Pressure Motor Ass'y	1	47	
019-65017-107	Write Pulse Motor	1	27	
019-65019-002	Clamp Motor	1	27	
019-80021-	System ROM; GR	1	57	
019-80031-	RPU	1	55	
019-80032-	RPE	1	55	
019-80033-	RPA	1	55	
019-91211-000	Unit/Main Motor; T	1	9	
019-91216-002	Main Motor Ass'y; T	1	9	
019-91220-107	Unit/Drive; CE	1	9	
019-91227-004	Main Shaft Ass'y; A3	1	9	
019-91228-000	Main Pulley; Main Shaft	1	9	
019-91230-102	Pressure Link Ass'y	1	9	
019-91231-001	P Disc Ass'y	1	9	
019-91310-009	Timing Roller Ass'y; A3	1	13	
019-91500-207	Unit/Paper-Feed Tray; A3; CE	1	7	
019-91501-203	Unit/Paper-Feed Tray; A3; US; CE	1	7	.
019-91600-007	Shaft; Elevator	1	5	
019-91712-000	Unit/Stripper (Dial)	1	13	
019-91720-002	Unit/Guide Plate; A3	1	13	
019-91800-103	Feed Tray Safety SW Ass'y; A3; CE	1	5	
019-91811-407	Scraper Ass'y; CE	1	5	
019-91830-002	P.-F. Pressure Adj. Lever Ass'y	1	5	
019-92101-004	Drum Holder Ass'y	1	25	
019-92110-003	Drum Body Ass'y; A3	1	23	

Part No.	Part Name	Q'ty	Page	Unit Value
019-92115-005	Unit/Drum Screen; A4W	1	23	
019-92120-009	Unit/Drum Screen; A3II	1	23	
019-92200-002	Unit/Squeegee; A3	1	15,19	
019-92220-003	Unit/Ink Pump; A3	1	19	
019-92230-203	Bottle Set SW Ass'y	1	20	
019-92231-005	Bottle Set SW Ass'y	1	16	
019-92237-003	Clamp Switch	1	27	
019-92240-004	Unit/Ink Pump; 37	1	15	
019-92320-008	Drum Set SW Ass'y	1	25	
019-92400-001	Unit/Clamp	1	27	
019-92410-007	Clamp Plate Base Ass'y	1	23	
019-93114-053	Unit/Paper Receiving Tray W	1	33	
019-93200-200	Suction Unit W; A3; CE	1	31	
019-93201-207	Paper Receiving Sensor IV (Receive) Ass'y	1	29	
019-93300-108	Separator Ass'y; A3; CE	1	29	
019-93310-006	Separation Fan Ass'y	1	29	
019-93320-109	Air Pump Ass'y	1	29	
019-93602-104	Unit/Clutch; A3	1	27	
019-94100-102	Unit/Master Removal; A3; CE	1	51	
019-94115-207	Holder Ass'y; V. - Transport Roller; A3; CE	1	51	
019-94130-109	Unit/Master Disposal Box; A3; CE	1	53	
019-95001-000	Unit/Master Making; A3	1	47	
019-95002-007	Unit/Master Making; A3 CE	1	47	
019-95037-056	TPH Ass'y; 600A3	1	47	
019-95041-002	Unit/Write Pulse Motor	1	27	
019-95050-052	Copy Guide Plate (Lower) Ass'y	1	47	
019-95070-100	Set Guide Plate Ass'y; A3	1	45	
019-95077-007	Write Roller, A3	1	45	
019-95095-005	Stocker Ass'y; A3	1	45	
019-95100-009	Set Sheet Plate Ass'y; A3	1	49	
019-95204-009	Unit/Master Roll Holder; 377	1	45	
019-95211-005	Guide Flange Ass'y	1	45	
019-95300-202	Unit/Cutter; A3; CE	1	49	
019-95600-001	Tension Roller Ass'y	1	45	
019-96050-005	Flat Bed PCB	1	41	
019-96105-101	Interlock Switch; FB	1	55	
019-96220-008	Ass'y/Digitizer cover; FB	1	63	
019-97008-100	Unit/Operation Panel; 3770 US	1	55	
019-97009-009	Unit/Operation Panel; 3770 Pic.	1	55	
019-97010-007	Unit/Operation Panel; 3770	1	55	
019-97058-000	Sub-Panel Ass'y; 3770 US	1	55	
019-97059-006	Sub-Panel Ass'y, 3770 Pic.	1	55	
019-97060-004	Sub-Panel Ass'y; 3770	1	55	
019-97090-000	LCD; Panel	1	55	
019-97150-003	Key Board Cover; 3770		55	

Part No.	Part Name	Q'ty	Page	Unit Value
019-97200-000	Front Cover Ass'y		59	
019-97220-001	Keyboard Bracket D Ass'y		3	
025-55001-005	Wire Harness; TM-I/F	1	65	
026-55040-008	Wire Harness; GR-TM2500	1	65	
101-55000-002	SCII Cable (Video Cable); 10 m	1	65	
101-55014-003	Parallel Cable IEEE	1	65	
408-02300-001	Battery	1	63	
408-02301-008	Battery; CR-2450	1	57	
435-00018-004	TDK Core; HF70SH40 x 1.3 x 8	1	43	
435-00020-009	Core; TR-23-11-14	1	61	
435-00025-000	Core; SFC-6	2	10,31	
435-00027-003	Ferrite Core; SFC-10	1	63	
443-00120-609	Micro-SW; E21-91N	1	25	
443-00121-109	Micro-SW; 21-52N	1	51	
443-00210-004	Micro-SW; DDIL-AIAA	2	55	
443-02000-708	Micro-SW; AM50630A331	3	5,7	
443-02004-002	Micro-SW: AM50039C331F	1	3	
443-02006-005	Micro-SW; ABV1236413	2	31	
443-02007-001	Micro-SW; AM50036C331	2	47	
443-02008-008	Micro-SW; AM50030C33	1	45	
443-10800-209	Power Switch; AJ921001B3	1	55	
443-30002-007	Sensor K; PS-R11LB	1	7	
443-30003-003	Sensor; LG-203D	7	5,9,41	
443-30005-006	Sensor; GP1A71A	2	9,51	
443-32001-008	Sensor S; GP2A20L	1	7	
480-00033-007	Power Cord; CH	1	57	
481-30004-000	Gasket; 80	2	41	
481-30007-000	Ground Finger	2	3	
481-30009-002	Gasket; PCB1	1	63	
481-30010-000	Gasket; PCB2	2	63	
481-30011-007	Gasket; PCB3	1	63	
481-30012-003	Gasket; LCDF	1	63	
481-30013-000	Gasket; LCDR	1	63	
484-00000-800	Pilot Lamp	2	16,20	
485-00001-804	Fuse 8A 125V 5.2 ULTS C	1	55	
485-00002-401	Fuse 10A 125V 5.2 ULTS C	1	55	
485-00003-203	Fuse 3.15A 250V 5.2 SET	5	55	
485-00003-300	Fuse 5A 250V 5.2 SET	1	55	
485-00003-408	Fuse 3.15A 125V ULTS C	5	55	
485-02520-000	Fuse 6.3A 250V 5.2 SET	1	55	
488-00013-103	Power Cord; 100V	1	57	
488-00014-100	Power Cord; US	1	57	
488-00015-106	Power Cord; 200V	1	57	
488-90009-002	Ground Wire; P. -F. -T.	1	7	
488-90019-105	Ground Wire; R4-440-R4	1	61	

Part No.	Part Name	Q'ty	Page	Unit Value
488-90021-002	Ground Wire; U3-1000-R4	1	3,57	
505-00350-102	Cap Spacer	1	47	
550-20059-108	Seal; P. -F. -T. Down	1	51	
550-20118-104	TPH Seal	1	47	
550-20590-105	Seal; P. -F. -T.	1	7	
550-20671-105	Seal; M. -M.	1	47	
550-20672-101	Seal; M. -M.; Pic.	1	47	
550-20682-107	Seal; Original Size	1	59	
550-20687-001	Seal; P.-Feed Pressure	1	5	
550-20688-008	Seal; P.-Feed Pressure; Pic.	1	5	
550-20690-002	Seal; Master Disposal	1	53	
550-20691-009	Seal; Master Disposal; Pic.	1	53	
550-20693-001	Seal; Set Disposal Box	1	53	
550-20694-008	Seal; Set Disposal Box; Pic.	1	53	
550-20760-000	Seal; Image Scanner	1	35	
550-20764-006	Digitizer Seal; Ja, US	1	63	
550-20861-001	Digitizer Seal; Gr	1	63	
550-20862-008	Digitizer Seal; Fr	1	63	
550-20863-004	Digitizer Seal; It	1	63	
550-20864-000	Digitizer Seal; Sp	1	63	
550-20865-007	Digitizer Seal; In	1	63	
550-20866-003	Digitizer Seal; Ch	1	63	
550-20867-000	Digitizer Seal; Kr	1	63	
550-20981-104	Seal; Ink (Black)	1	20	
550-20982-100	Seal; Ink (Black); Pic.	1	20	
550-20983-000	Seal; Drum Holder	1	25	
550-20984-006	Seal; Drum Holder; Pic.	1	25	
550-20987-005	Seal; Setting Master	1	45	
550-20988-001	Seal; Setting Master, Pic.	1	45	
550-20998-007	Seal; Manual Pocket	1	59	
550-21073-007	Seal; P -Rcv. -T.; Caution	1	45	
550-21121-001	Seal; P. -F. -T.; US	1	7	
550-21141-002	Seal; Paper Guide Set	1	45	
550-21142-009	Seal; Paper Guide Set; Pic.	1	45	
550-21292-108	Seal; Paper Side Guide	1	7	
550-21293-007	Color Seal Set		16,20	
550-21296-103	Seal; P. -Rcv. -T.; US		33	
550-21298-106	Seal; P. -Rcv. -T.; Pic.		33	
550-21299-102	Seal; P. -Rcv. -T.		33	
550-21301-000	Seal; Master Cut	1	3	
550-21302-006	Seal; Master Cut; Pic.	1	3	
550-21399-000	Seal; Ink (HD Black)	1	16	
550-21502-005	Seal; Ink (HD Black); CH	1	16	
552-21400-105	Seal; Ink (HD Black); Pic.	1	16	
600-06105-001	Bearing; DDLF - 1060ZZH	2	45	

Part No.	Part Name	Q'ty	Page	Unit Value
600-06172-108	Bearing; DDR-1760 x 2 ZZR	1	43	
600-08168-000	Bearing NMB; LNR-1680HH	2	31	
600-08168-108	Bearing; SC866ZZNR/1K	2	27	
600-08242-006	Bearing; 628ZZ	6	9	
600-20061-009	Bearing; 608ZZ	1	9	
600-50046-004	Bearing; FLAWBC6-12ZZA	4	31,43	
600-50059-017	Bearing; FLW688ZZ	1	13	
601-10192-005	Bearing; 6800ZZ	4	15,19	
601-10228-000	Bearing; 0900ZZNR	2	45	
607-03000-005	Metal; S4 x 8 x 3	2	27	
607-05001-009	Metal; S6 x 10 x 6	1	45	
607-09001-003	Metal; S14 x 18 x 4.5	2	3	
607-10000-010	Metal; F3 x 5 x 3; 8 x 1.4	2	15,19	
607-11000-200	Metal; F4 x 7 x 6; 10 x 1.5	2	47	
607-11001-002	Metal; F4 x 6 x 2.2; 8 x 1	1	9	
607-11003-005	Metal; F4 x 6/5.6 x 5.9; 9 x 1	2	31	
607-12001-006	Metal; F5 x 10/9 x 4; 12 x 1.5	1	5	
607-13000-003	Metal; F6 x 10/9 x 4; 12 x 1.5	6	9,31,51	
607-13000-402	Metal; F6 x 10/9 x 6; 12 x 1.5	4	13,51	
607-13000-607	Metal; F6 x 9 x 7; 11 x 1	2	47	
607-13003-002	Metal; F6 x 8 x 3; 10 x 1	2	47	
607-13004-009	Metal; F6 x 8 x 7; 10 x 1	1	27	
607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	4	5,13,29	
607-15000-809	Metal; F8 x 16 x 6; 18 x 2	2	45	
607-15002-003	Metal; F8 x 12 x 5; 16 x 2	2	9	
607-15006-009	Metal; F8 x 16 x5; 18 x 1.1	2	7	
607-16000-403	Metal; F10 x 15/14 x 5.5; 20 x 2.5	1	5	
607-16000-802	Metal; F10 x 18/16 x 5; 22 x 1.5	2	5	
607-17000-105	Metal; F12 x 18 x 10; 24 x 2.5	2	13	
607-70815-005	Washer; UH3000	1	9	
610-00002-207	Damper; FB	2	41	
610-00007-004	HG Damper, 2G50-E	1	45	
611-01420-000	Pulley; ϕ 14 x 8	1	43	
611-30090-000	Pulley; P63/20-2M-6; HTD	1	43	
611-42100-001	Pulley; P21-3M060 (HTD)	1	5	
611-42600-004	Pulley; P26-3M060 (HTD)	1	5	
612-03103-009	Gear B; 1.25 x 14	2	51	
620-20714-005	Belt; B71M x L4.8	1	27	
620-21209-002	Squeegee Belt; B120M x L-9.5	2	15,19	
620-21869-002	Belt; B186 M x L-9.5	1	27	
620-22394-008	Belt; 239-M x L-4.8	1	31	
620-31776-002	Belt; 177-3M-6	1	5	
620-32916-002	Belt; 291-3M-6	1	51	
620-62256-007	Belt; B60S3M225	1	31	
620-73758-004	Belt; 375-5GT-8	1	29	

Part No.	Part Name	Q'ty	Page	Unit Value
620-78309-003	Belt; 830-5GT-11	1	9	
620-81966-007	Belt; 196-2GT	1	43	
620-89996-100	Belt; 1344-2GT	1	43	
620-97506-006	Belt; 750-3GT-6	2	9,27	
634-05020-000	Collar; ϕ 5.1 x 2.5	1	27	
634-06060-006	Collar; ϕ6 x 6	1	27	
634-06120-009	Collar; ϕ6 x 12	1	27	
635-11307-106	Stepped Screw; 3 x 7	10	61	
635-17523-005	Stepped Screw; ϕ5x2; M3x3	1	13	
635-17613-004	Stepped Screw; M3 x 4	1	5	
635-17614-000	Stepped Screw, M4 x 4.5	2	47	
635-17624-006	Stepped Screw; ϕ6x2.2; M4x2.5	1	13	
635-17814-000	Stepped Screw; M4 x 4.3	1	41	
635-19404-003	Stepped Screw; M4 x 4.5	1	55	
638-90000-012	Washer; 18 x 10.4 x 0.4	1	5	
638-90000-020	Washer; 18 x 10.2 x 0.2	6	15,19	
638-90616-005	Washer; 6.1 x 12 x 1.6	3	7,9	
638-90804-006	Washer; 8 x 15 x 0.4	1	9	
639-00405-008	Washer; 4 x 6.5 x 0.5	1	35	
640-60080-001	O Ring; P8-1.9	4	15,19	
640-60100-118	O Ring; P10A-2.4	2	16,20	
640-60140-012	O Ring; P14-2.4	6	15,19	
640-60220-024	O Ring; P22-2.4	2	16,20	
640-67340-009	O Ring; P34-3.6	1	29	
640-70030-100	V Ring; VRY2.7 x 3.5 x 4.1	2	15,19	
660-01000-200	Rubber Foot K-45	4	3	
660-05000-018	Magnet Catch SM50P	2	3	
660-05000-301	Magnet Catch; SM-41	1	5	
665-02025-504	Wire Saddle; WS-4W	3	55	
665-02031-008	Clamp; CP2311	2	31	
665-02040-007	Wire Saddle; LWS-2N-VO-MB6	2	57	
665-02901-002	Power Band T10	2	29	
665-04014-003	Snap Bushing; SB-2000-26	3	47,57	
665-04037-003	Free Bushing; NJ-23	1	57	
665-04950-205	Nut; E-632	4	27	
665-04951-104	Clip; Stylus Pen Holder	1	63	
665-09004-006	Stylus Pen Holder	1	63	

Part No.	Part Name	Q'ty	Page	Unit Value
X-500	Pin; ϕ 2 x 8	10		
X-510	Pin; ϕ 2 x 10	10		
X-520	Pin; ϕ 2 x 12	10		
X-530	Pin; ϕ 2 x 14	10		
X-540	Pin; ϕ 2.5 x 8	10		
X-600	Junction Connector; 2P	5		
X-610	Junction Connector; 3P	5		
X-620	Junction Connector; 4P	5		
X-630	Junction Connector; 5P	5		
X-640	Junction Connector; 6P	5		
X-650	Plastic E Ring	10		
The orders for the above (X-000) numbered Parts are available only by quantities of tens or fives as indicated.				